

Brother DCP-6690/MFC-5890/5895/6490/6890	Brother LC1100 Black Std Cap
Brother DCP-6690/MFC-5890/5895/6490/6890	Brother LC1100 Cyan Std Cap
Brother DCP-6690/MFC-5890/5895/6490/6890	Brother LC1100 Magenta Std Cap
Brother DCP-6690/MFC-5890/5895/6490/6890	Brother LC1100 Yellow Std Cap
Brother DCP-J152W / J552DW / J752DW / MFC-J470DW / J650DW	Brother LC121 Black
Brother DCP-J152W / J552DW / J752DW / MFC-J470DW / J650DW	Brother LC121 Cyan
Brother DCP-J152W / J552DW / J752DW / MFC-J470DW / J650DW	Brother LC121 Magenta
Brother DCP-J152W / J552DW / J752DW / MFC-J470DW / J650DW	Brother LC121 Yellow
Brother DCP-J4110DW/MFC-J4410 / J4510 / J4610 / J4710	Brother LC123 Black
Brother DCP-J4110DW/MFC-J4410 / J4510 / J4610 / J4710	Brother LC123 Cyan
Brother DCP-J4110DW/MFC-J4410 / J4510 / J4610 / J4710	Brother LC123 Magenta
Brother DCP-J4110DW/MFC-J4410 / J4510 / J4610 / J4710	Brother LC123 Yellow
Brother MFC-J6510DW / J6710D	Brother LC1240 Black
Brother MFC-J6510DW / J6710D	Brother LC1240 Cyan
Brother MFC-J6510DW / J6710D	Brother LC1240 Magenta
Brother MFC-J6510DW / J6710D	Brother LC1240 Yellow
Brother DCP-J4110DW / MFC-J4410 / J4510 / J4610 / J4710	Brother LC125XL Cyan
Brother DCP-J4110DW / MFC-J4410 / J4510 / J4610 / J4710	Brother LC125XL Magenta
Brother DCP-J4110DW / MFC-J4410 / J4510 / J4610 / J4710	Brother LC125XL Yellow
Brother DCP-J4110DW / MFC-J4410 / J4510 / J4610 / J4710	Brother LC127XL Black
Brother MFC-J6510DW / J6710D	Brother LC1280XL Black
Brother MFC-J6510DW / J6710D	Brother LC1280XL Cyan
Brother MFC-J6510DW / J6710D	Brother LC1280XL Magenta
Brother MFC-J6510DW / J6710D	Brother LC1280XL Yellow
Brother MFC-J6520DW / MFC-J6720DW / MFC-J6920DW	Brother LC129XL Black
Brother DCP-J4120DW/J4420DW/J620DW/J4625DW/J5320DW/J5	Brother LC223 Black
Brother DCP-J4120DW/J4420DW/J620DW/J4625DW/J5320DW/J5	Brother LC223 Cyan
Brother DCP-J4120DW/J4420DW/J620DW/J4625DW/J5320DW/J5	Brother LC223 Magenta
Brother DCP-J4120DW/J4420DW/J620DW/J4625DW/J5320DW/J5	Brother LC223 Yellow
Brother DCP-J4120DW/J4420DW/J620DW/J4625DW/J5320DW/J5	Brother LC227XL Black
Brother DCP-J4120DW/J4420DW/J620DW/J4625DW/J5320DW/J5	Brother LC225XL Cyan
Brother DCP-J4120DW/J4420DW/J620DW/J4625DW/J5320DW/J5	Brother LC225XL Magenta
Brother DCP-J4120DW/J4420DW/J620DW/J4625DW/J5320DW/J5	Brother LC225XL Yellow
Brother MFC-J5320DW / J5620DW / J5625DW / J5720DW	Brother LC229XL Black

Canon Inkjet Printers	Canon Inkjet Printers
-----------------------	-----------------------

Canon BJ-10 / BJ-5 / BJ-20	Canon BC-01 Black
Canon BJ100 / 200 / 220 / 230 / BJC-150 / 210 / 240	Canon BC-02 Black
Canon B 140 / 150 / 160 / 170 / 310 / 320 / 340 / 360	Canon BX-2 Black
Canon FAXPHONE B740	Canon BX-20 Black
Canon FAXPHONE B45, B540, B550, B640, B95, MultiPASS 800	Canon BX-3 Black
Canon Pixma iP1800/2500 Colour	Canon CL-38 Colour
Canon IP2200 / IP1600 / 150 / 170 / 450 PIXMA	Canon CL-41 Colour
Canon Pixma MG3140 / MX374 / MX434 / MX514	Canon CL-441XL Colour
Canon MP450 Photo / iP6210 / iP6220	Canon CL-51 Colour
Canon Pixma MP240/260/480	Canon CL-511 Colour
Canon Pixma MP240/260/480	Canon CL-513 Colour
Canon PIXMA iP6220/iP6210	Canon CL-52 Colour Photo
Canon Pixma MG2150 / 3150 / 4150 / MX375 / 435 / 515	Canon CL-541 Colour
Canon Pixma MG2150 / 3150 / 4150 / MX375 / 435 / 515	Canon CL-541XL Colour
Canon Pixma iP2850 / Pixma MG2450 / Pixma MG2550	Canon CL-546 Colour
Canon Pixma iP2850 / Pixma MG2450 / Pixma MG2550	Canon CL-546XL Colour
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571 Black
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571XL Black
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571 Cyan
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571XL Cyan
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571 Magenta
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571XL Magenta
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571 Yellow
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571XL Yellow
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571 Gray
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon CLI-571XL Gray

Canon ImagePROGRAF iPF5000 / iPF6000S / iPF6200	Canon PFI-101 series All Colours
Canon ImagePROGRAF iPF500/510/600/605/610/700/710/720/LP17	Canon PFI-102 series All Colours
Canon ImagePROGRAF iPF5100 / iPF6100 / iPF6200	Canon PFI-103 series All Colours
Canon ImagePROGRAF iPF650 / 750 / MFPM40 / 755 / 765	Canon PFI-104 series All Colours
Canon ImagePROGRAF iPF6300 / iPF6350 / iPF6400 / iPF6450	Canon PFI-106 series All Colours
Canon ImagePROGRAF iPF670/680/685/770/780/785	Canon PFI-107 series All Colours
Canon ImagePROGRAF iPF680 / iPF685 / iPF780 / iPF785	Canon PFI-207 series All Colours
Canon ImagePROGRAF iPF8000/8000S/8100/9000/9000S/9100	Canon PFI-701 series All Colours
Canon ImagePROGRAF iPF8300s/iPF8400/iPF8400SE/iPF9400	Canon PFI-706 series All Colours
Canon ImagePROGRAF iPF830 / iPF840 / iPF850	Canon PFI-707 series All Colours
Canon Pixma iP1800/2500 Black	Canon PG-37 Black
Canon IP2200 / IP1600 / 150 / 170 / 450 PIXMA	Canon PG-40 Black
Canon Pixma MG3140 / MX374 / MX434 / MX514	Canon PG-440XL Black
Canon Pixma iP1600	Canon PG-50 Black
Canon Pixma MP240/260/480	Canon PG-510 Black
Canon Pixma MP240/260/480	Canon PG-512 Black
Canon Pixma MG2150 / 3150 / 4150 / MX375 / 435 / 515	Canon PG-540 Black
Canon Pixma MG2150 / 3150 / 4150 / MX375 / 435 / 515	Canon PG-540XL Black
Canon Pixma iP2850 / Pixma MG2450 / Pixma MG2550	Canon PG-545 Black
Canon Pixma iP2850 / Pixma MG2450 / Pixma MG2550	Canon PG-545XL Black
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon PGI-570 Black
Canon Pixma MG5750/51/52/53/MG6850/51/52/53/MG7750/51/52/53	Canon PGI-570XL Black

Remanufactured / Refilled Canon Inkjet Printers	Remanufactured / Refilled Canon Inkjet Printers
---	---

Canon IP2200 / IP1600 / 150 / 170 / 450 PIXMA	Canon PG-40 Black (REMAN/REFILLED)
Canon Pixma iP1800/2500 Colour	Canon CL-38 Colour (REMAN/REFILLED)
Canon MP450 Photo / iP6210 / iP6220	Canon CL-51 Colour (REMAN/REFILLED)
Canon IP2200 / IP1600 / MP150 / MP170 / MP450 PIXMA	Canon CL-41 Colour (REMAN/REFILLED)
Canon Pixma MG3140 / MX374 / MX434 / MX514	Canon CL-441XL Colour (REMAN/REFILLED)
Canon Pixma MP240/260/480	Canon CL-511 Colour (REMAN/REFILLED)
Canon Pixma MP240/260/480	Canon CL-513 Colour (REMAN/REFILLED)
Canon Pixma MG2150 / 3150 / 4150 / MX375 / 435 / 515	Canon CL-541 Colour (REMAN/REFILLED)
Canon Pixma MG2150 / 3150 / 4150 / MX375 / 435 / 515	Canon CL-541XL Colour (REMAN/REFILLED)
Canon Pixma iP2850 / Pixma MG2450 / Pixma MG2550	Canon CL-546 Colour (REMAN/REFILLED)
Canon Pixma iP2850 / Pixma MG2450 / Pixma MG2550	Canon CL-546XL Colour (REMAN/REFILLED)
Canon Pixma MG3140 / MX374 / MX434 / MX514	Canon PG-440XL Black (REMAN/REFILLED)
Canon Pixma iP1600	Canon PG-50 Black (REMAN/REFILLED)
Canon Pixma MP240/260/480	Canon PG-510 Black (REMAN/REFILLED)
Canon Pixma MP240/260/480	Canon PG-512 Black (REMAN/REFILLED)
Canon Pixma MG2150 / 3150 / 4150 / MX375 / 435 / 515	Canon PG-540 Black (REMAN/REFILLED)
Canon Pixma MG2150 / 3150 / 4150 / MX375 / 435 / 515	Canon PG-540XL Black (REMAN/REFILLED)
Canon Pixma iP2850 / Pixma MG2450 / Pixma MG2550	Canon PG-545 Black (REMAN/REFILLED)
Canon Pixma iP2850 / Pixma MG2450 / Pixma MG2550	Canon PG-545XL Black (REMAN/REFILLED)

Dell Inkjet Printers	Dell Inkjet Printers
----------------------	----------------------

Dell 948/V505/V505w	Dell Series 11 / JP451 Black
Dell 948/V505/V505w	Dell Series 11 / JP453 Colour
Dell 948/V505/V505w	Dell Series 11 / KX701 Black
Dell 948/V505/V505w	Dell Series 11 / KX703 Colour
Dell V105 All-In-One	Dell Series 15 / UK852 Colour
Dell V105 All-In-One	Dell Series 15 / WP322 Black
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964	Dell Series 5 / J5566 Black
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964	Dell Series 5 / J5567 Colour
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964	Dell Series 5 / M4640 Black
Dell 922 / 924 / 942 / 944 / 946 / 962 / 964	Dell Series 5 / M4646 Colour
Dell 725 / 810 / All In One	Dell Series 6 / JF333 Colour
Dell 966	Dell Series 7 / CH883 Black
Dell 966 / 968	Dell Series 7 / CH884 Colour
Dell 966	Dell Series 7 / DH828 Black
Dell 966	Dell Series 7 / DH829 Colour
Dell 926	Dell Series 9 / MK990 Black
Dell 926	Dell Series 9 / MK991 Colour
Dell 926	Dell Series 9 / MK992 Black

Dell 926	Dell Series 9 / MK993 Colour
Epson	Epson InkJet Printers
Epson WF-2010W\WF-2510WF\WF-2520NF\WF-2530WF\WF-254	Epson 16 All Colours
Epson WF-2010W\WF-2510WF\WF-2520NF\WF-2530WF\WF-254	Epson 16XL All Colours
Epson 18XL All Colours	Epson 18XL All Colours
Epson 24XL All Colours	Epson 24XL All Colours
Epson 26XL All Colours	Epson 26XL All Colours
Epson Extra High Cap Black 27XXL T2791	Epson 27XXL T2791
Epson 27XL All Colours	Epson 27XL All Colours
Epson 29 All Colours	Epson 29 All Colours
Epson 29XL All Colours	Epson 29XL All Colours
Epson 33 All Colours	Epson 33 All Colours
Epson 33XL All Colours	Epson 33XL All Colours
Epson T0711 / 12 / 13 / 14	Epson T0711 / 12 / 13 / 14
HP Inkjet Printers	HP Inkjet Printers
HP Photosmart 8750	HP 102 / C9360A High Photo Grey
HP Psmart 475/A310/311/314/316/320/430/432/433/434/436/440/44	HP 110 / CB304A Colour
HP Designjet CP-1160/Officejet 7110/7130/7140/D125/D135/D145/	HP 14A C5011A Black
HP Designjet CP-1160/Officejet 7110/7130/7140/D125/D135/D145/	HP 14A C5010A Colour
HP 310/3810/3816/3820/3822/810/12/16/25/40/41/42/43/45/916/920	HP 15 / C6615 Black
HP DJ 840/843	HP 17 / C6625A
HP DJ 610/612/640	HP 20 / C6614A/D
HP DJ 3920/3940/1410	HP 21 / C9351AE Black
HP DJ 3920/3940/1410	HP 21XL / C9351CE Black
HP DJ 3920/3940/1410	HP 21 / C9351 Black INTRO
HP DJ 3920/3940/1410	HP 21 / C9351AE Black Small
HP DJ 3920/3940/1410	HP 22 / C9352AE Colour
HP DJ 3920/3940/1410	HP 22XL / C9352CE Colour
HP DJ 3920/3940/1410	HP 22 / C9352 INTRO
HP 700 / 800 / 1000 / 1100 series	HP 23 / C1823A/D Colour
HP 400 / 500 series	HP 26 / 51626A/G Black
HP DJ 3320/3325/3420/3550	HP 27 / C8727AE Black
HP DJ 3320/3325/3420/3550	HP 28 / C8728AE Colour
HP DJ F4280	HP 300 / CC639EE Black INTRO
HP DJ F4280	HP 300 / CC640EE Black
HP DJ F4280	HP 300 / CC642EE Colour INTRO
HP DJ F4280	HP 300 / CC643EE Colour
HP DJ F4280	HP 300XL / CC641EE Black
HP DJ F4280	HP 300XL / CC644EE Colour
HP DeskJet 1000/1050/2050/2510/3000/3050/3055A	HP 301 / CH561EE Black (OLD VERSION)
HP DeskJet 1000/1050/2050/2510/3000/3050/3055A	HP 301 / CH562EE Colour (OLD VERSION)
HP Deskjet 1010/1510/12/14/2512/40/42/44/49/Envy 4500 Series	HP 301 V1 / CH561EE Black (NEW VERSION)
HP Deskjet 1010/1510/12/14/2512/40/42/44/49/Envy 4500 Series	HP 301 V1 / CH562EE Colour (NEW VERSION)
HP DeskJet 1000/1050/2050/2510/3000/3050/3055A	HP 301XL / CH563EE Black (OLD VERSION)
HP DeskJet 1000/1050/2050/2510/3000/3050/3055A	HP 301XL / CH564EE Colour (OLD VERSION)
HP Deskjet 1010/1510/12/14/2512/40/42/44/49/Envy 4500 Series	HP 301XL V1 / CH563EE Black (NEW VERSION)
HP Deskjet 1010/1510/12/14/2512/40/42/44/49/Envy 4500 Series	HP 301XL V1 / CH564EE Colour (NEW VERSION)
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Black / F6U66AE
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302XL Black / F6U68AE
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Colour / F6U65AE
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302XL Colour / F6U67AE
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Black (NOT SETUP H)
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Colour (NOT SETUP H)
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Black (SETUP H)
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Colour (SETUP H)
HP Deskjet 3720/3730/3732/3733	HP 304 Black / N9K06AE
HP Deskjet 3720/3730/3732/3733	HP 304XL Black / N9K08AE
HP Deskjet 3720/3730/3732/3733	HP 304 Colour / N9K05AE
HP Deskjet 3720/3730/3732/3733	HP 304XL Colour / N9K07AE
HP Deskjet 3720/3730/3732/3733	HP 304 Black (NOT SETUP H)
HP Deskjet 3720/3730/3732/3733	HP 304 Colour (NOT SETUP H)

HP Deskjet 3720/3730/3732/3733	HP 304 Black (SETUP H)
HP Deskjet 3720/3730/3732/3733	HP 304 Colour (SETUP H)
HP 300 series	HP 33 / 51633M Black
HP DJ 5400 Series	HP 336 / C9362EE Black
HP Photosmart 2570	HP 337 / C9364EE Black
HP DJ 5740/6520/6540/6540dt/6840	HP 338 / C8765EE Black
HP DJ 5740/6520/6540/6540dt/6840	HP 339 / C8767EE Black
HP DJ 5400 Series	HP 342 / C9361EE Colour
HP DJ 5740/6520/6540/6540dt/6840	HP 343 / C8766EE Colour
HP DJ 5740/6520/6540/6540dt/6840	HP 344 / C9363EE Colour
HP DJ 5740/6520/6540/6540dt/6840	HP 348 / C9369EE Photo
HP DJ D4260/OfficeJet J5780	HP 350 / CB335EE Black
HP DJ D4260/OfficeJet J5780	HP 350XL / CB336EE Black
HP DJ D4260/OfficeJet J5780	HP 351 / CB337EE Colour
HP DJ D4260/OfficeJet J5780	HP 351XL / CB338EE Colour
HP Photosmart B8550/C5380/C6380/D5460	HP 364 / CN680E Black
HP Photosmart B8550/C5380/C6380/D5460	HP 364XL / CN684E Black
HP Photosmart B8550/C5380/C6380/D5460	HP 364XL / CR277E Black Photo
HP Photosmart B8550/C5380/C6380/D5460	HP 364 / CN681E Cyan
HP Photosmart B8550/C5380/C6380/D5460	HP 364XL / CN685E Cyan
HP Photosmart B8550/C5380/C6380/D5460	HP 364 / CN682E Magenta
HP Photosmart B8550/C5380/C6380/D5460	HP 364XL / CN686E Magenta
HP Photosmart B8550/C5380/C6380/D5460	HP 364 / CN683E Yellow
HP Photosmart B8550/C5380/C6380/D5460	HP 364XL / CN687E Yellow
HP DesignJet 230/250C/330/350C/400 Series/650/CopyJet	HP 40 / 51640A Black
HP DeskJet 750/755/Designjet 350C/450C/455C/488C/750C/755CM	HP 44 / 51644 Cyan
HP DeskJet 750/755/Designjet 350C/450C/455C/488C/750C/755CM	HP 44 / 51644 Magenta
HP DeskJet 750/755/Designjet 350C/450C/455C/488C/750C/755CM	HP 44 / 51644 Yellow
HP 700 / 800 / 1000 / 1100 / 1600 series	HP 45 / 51645A Black
HP DJ 420ci/cbi/5150/5550c/5552	HP 56 / C6656A Black
HP DJ 420ci/cbi/5150/5550c/5552	HP 56 / C6656G Black Small
HP DJ 420ci/cbi/5150/5550c/5552	HP 57 / C6657A Colour
HP DJ 420ci/cbi/5150/5550c/5552	HP 57 / C6657GE Colour Small
HP DJ 420ci/cbi/5150/5550c/5552	HP 58 / C6658A Photo
HP Envy 5640 e-All-in-One / 7640 / Officejet 5740	HP 62 / C2P04A Black
HP Envy 5640 e-All-in-One / 7640 / Officejet 5740	HP 62 / C2P06A Colour
HP Envy 5640 e-All-in-One / 7640 / Officejet 5740	HP 62XL / C2P05A Black
HP Envy 5640 e-All-in-One / 7640 / Officejet 5740	HP 62XL / C2P07A Colour
HP Deskjet Ink Advantage 2515 and 2515 e-All-in-One	HP 650 / CZ101AE Black
HP Deskjet Ink Advantage 2515 and 2515 e-All-in-One	HP 650 / CZ102AE Colour
HP Fax 640 printer	HP 701 / CC635A Black
HP Designjet T120 / T520 ePrinter	HP 711 / CZ129A Std Cap Black
HP Designjet T120 / T520 ePrinter	HP 711 / CZ133A Hi Cap Black
HP Designjet T120 / T520 ePrinter	HP 711 / CZ130A Cyan
HP Designjet T120 / T520 ePrinter	HP 711 / CZ131A Magenta
HP Designjet T120 / T520 ePrinter	HP 711 / CZ136A Yellow
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9370A Hi Cap Photo Black
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9371A Hi Cap Cyan
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9372A Hi Cap Magenta
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9373A Hi Cap Yellow
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9374A Hi Cap Gray
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9397A Photo Black
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9398A Cyan
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9399A Magenta
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9400A Yellow
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9401A Gray
HP DesignJet T1100/T1120HD/T1200/T1300/T2300/T610/T620/T7	HP 72 / C9403A Matte Black
HP DeskJet 930/950/970/980/990/G55/G85/G95	HP 77X Plus / CB277A Color
HP DeskJet 930/950/970/980/990/G55/G85/G95	HP 78A / C6578A 38ML Colour
HP DeskJet 930/950/970/980/990/G55/G85/G95	HP 78D / C6578D 19ML Colour
HP Designjet 500 / 510 / 800	HP 82 / CH565A 69ml Black

HP Designjet 500 / 510 / 800	HP 82 / C4911A 69ml Cyan
HP Designjet 500 / 510 / 800	HP 82 / C4912A 69ml Magenta
HP Designjet 500 / 510 / 800	HP 82 / C4913A 69ml Yellow
HP Designjet 4000 / 4500 / 4520HD	HP 90 / C5061A Hi Cap Cyan
HP Designjet 4000 / 4500 / 4520HD	HP 90 / C5063A Hi Cap Magenta
HP Designjet 4000 / 4500 / 4520HD	HP 90 / C5065A Hi Cap Yellow
HP OfficeJet J4580 / J4660 / 4680	HP 901 / CC563AE Black
HP OfficeJet J4580 / J4660 / 4680	HP 901 / CC656AE Colour
HP OfficeJet J4580 / J4660 / 4680	HP 901XL / CC654AE Black
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 / T6L99AE Black
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 / T6L87AE Cyan
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 / T6L91AE Magenta
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 / T6L95AE Yellow
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 Black INTRO
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 Cyan INTRO
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 Magenta INTRO
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 Yellow INTRO
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903XL / T6M15AE Black
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903XL / T6M03AE Cyan
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903XL / T6M07AE Magenta
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903XL / T6M11AE Yellow
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 907XL / T6M19AE Black
HP PageWide Pro 352/377/452/477	HP 913A / L0R95AE Black
HP PageWide Pro 352/377/452/477	HP 913A / F6T77AE Cyan
HP PageWide Pro 352/377/452/477	HP 913A / F6T78AE Magenta
HP PageWide Pro 352/377/452/477	HP 913A / F6T79AE Yellow
HP PageWide Pro 352/377/452/477	HP 913A / L0R95AE Black (NOT SETUP H)
HP PageWide Pro 352/377/452/477	HP 913A / F6T77AE Cyan (NOT SETUP H)
HP PageWide Pro 352/377/452/477	HP 913A / F6T78AE Magenta (NOT SETUP H)
HP PageWide Pro 352/377/452/477	HP 913A / F6T79AE Yellow (NOT SETUP H)
HP OfficeJet 6000 / 6500 / 7000	HP 920XL / CD975AE Black
HP OfficeJet 6000 / 6500 / 7000	HP 920XL / CD972AE Cyan
HP OfficeJet 6000 / 6500 / 7000	HP 920XL / CD973AE Magenta
HP OfficeJet 6000 / 6500 / 7000	HP 920XL / CD974AE Yellow
HP Officejet 6100e/6600 /6700 Premium e-All-in-one	HP 932 / CN057AE Black
HP Officejet 6100e/6600 /6700 Premium e-All-in-one	HP 932XL / CN053AE Black
HP Officejet 6100e/6600 /6700 Premium e-All-in-one	HP 933XL / CN054AE Cyan
HP Officejet 6100e/6600 /6700 Premium e-All-in-one	HP 933XL / CN055AE Magenta
HP Officejet 6100e/6600 /6700 Premium e-All-in-one	HP 933XL / CN056AE Yellow
HP Officejet Pro 6230 ePrinter / 6830 e-All-in-One	HP 934 / C2P19AE Black
HP Officejet Pro 6230 ePrinter / 6830 e-All-in-One	HP 935 / C2P20AE Cyan
HP Officejet Pro 6230 ePrinter / 6830 e-All-in-One	HP 935 / C2P21AE Magenta
HP Officejet Pro 6230 ePrinter / 6830 e-All-in-One	HP 935 / C2P22AE Yellow
HP Officejet Pro 6230 ePrinter / 6830 e-All-in-One	HP 934XL / C2P23AE Black
HP Officejet Pro 6230 ePrinter / 6830 e-All-in-One	HP 935XL / C2P24AE Cyan
HP Officejet Pro 6230 ePrinter / 6830 e-All-in-One	HP 935XL / C2P25AE Magenta
HP Officejet Pro 6230 ePrinter / 6830 e-All-in-One	HP 935XL / C2P26AE Yellow
HP Officejet Pro 8000 9500	HP 940XL / C4906AE Black
HP Officejet Pro 8000 9500	HP 940XL / C4907AE Cyan
HP Officejet Pro 8000 9500	HP 940XL / C4908AE Magenta
HP Officejet Pro 8000 9500	HP 940XL / C4909AE Yellow
HP Officejet Pro 8100e / 8600	HP 950XL / CN045AE Black
HP Officejet Pro 8100e / 8600	HP 951XL / CN046AE Cyan
HP Officejet Pro 8100e / 8600	HP 951XL / CN047AE Magenta
HP Officejet Pro 8100e / 8600	HP 951XL / CN048AE Yellow
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 / L0S58AE Black
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 / F6U12AE Cyan
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 / F6U13AE Magenta
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 / F6U14AE Yellow
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953XL / L0S70AE Black
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953XL / F6U16AE Cyan

HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953XL / F6U17AE Magenta
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953XL / F6U18AE Yellow
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 Black (NOT SETUP H)
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 Cyan (NOT SETUP H)
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 Magenta (NOT SETUP H)
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 Yellow (NOT SETUP H)
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 970 / CN621AE Black
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 970 / Black INTRO
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 970XL / CN625AE Black
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971 / CN622AE Cyan
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971 / CN623AE Magenta
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971 / CN624AE Yellow
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971 Cyan INTRO
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971 Magenta INTRO
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971 Yellow INTRO
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971XL / CN626AE Cyan
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971XL / CN627AE Magenta
HP Officejet Pro X451dw/X476dw/X551dw/X576dw	HP 971XL / CN628AE Yellow
HP PageWide Pro 452dw / 477dw	HP 973X / L0S07AE Black
HP PageWide Pro 452dw / 477dw	HP 973X / F6T81AE Cyan
HP PageWide Pro 452dw / 477dw	HP 973X / F6T82AE Magenta
HP PageWide Pro 452dw / 477dw	HP 973X / F6T83AE Yellow
HP PageWide Pro 452dw / 477dw	HP 973 Black INTRO
HP PageWide Pro 452dw / 477dw	HP 973 Cyan INTRO
HP PageWide Pro 452dw / 477dw	HP 973 Magenta INTRO
HP PageWide Pro 452dw / 477dw	HP 973 Yellow INTRO
HP Officejet Enterprise Colour Flow X585z/X555dn/X555xh/X585d	HP 980 Black / D8J10A
HP Officejet Enterprise Colour Flow X585z/X555dn/X555xh/X585d	HP 980 Cyan / D8J07A
HP Officejet Enterprise Colour Flow X585z/X555dn/X555xh/X585d	HP 980 Magenta / D8J08A
HP Officejet Enterprise Colour Flow X585z/X555dn/X555xh/X585d	HP 980 Yellow / D8J09A
HP Officejet Enterprise Colour Flow X585z/X555dn/X555xh/X585d	HP 980 Black / D8J10A INTRO
HP Officejet Enterprise Colour Flow X585z/X555dn/X555xh/X585d	HP 980 Cyan / D8J07A INTRO
HP Officejet Enterprise Colour Flow X585z/X555dn/X555xh/X585d	HP 980 Magenta / D8J08A INTRO
HP Officejet Enterprise Colour Flow X585z/X555dn/X555xh/X585d	HP 980 Yellow / D8J09A INTRO
HP Psmart 475/A310/311/314/316/320/430/432/433/434/436/440/44	HP 110 / CB304A Colour
HP 310/3810/3816/3820/3822/810/12/16/25/40/41/42/43/45/916/920	HP 15 / C6615A\D Black (REMAN/REFILLED)
HP DJ 3920/3940/1410 Black	HP 21 / C9351AE Black (REMAN/REFILLED)
HP DJ 3920/3940/1410 Black	HP 21 / C93521 Low Vol Black (REMAN/REFILLED)
HP DJ 3920/3940/1410 Black	HP 21XL / C9351CE Black (REMAN/REFILLED)
HP DJ 3920/3940/1410 Colour	HP 22 / C9352 INTRO (REMAN/REFILLED)
HP DJ 3920/3940/1410 Colour	HP 22 / C9352AE Colour (REMAN/REFILLED)
HP DJ 3920/3940/1410 Colour	HP 22XL / C9352CE Colour (REMAN/REFILLED)
HP DJ 3320/3325/3420/3550 Black	HP 27 / C8727AE Black (REMAN/REFILLED)
HP DJ 3320/3325/3420/3550 Colour	HP 28 / C8728AE Colour (REMAN/REFILLED)
HP DJ F4280 Black	HP 300 / CC639EE Black INTRO (REMAN/REFILLED)
HP DJ F4280 Black	HP 300 / CC640EE Black (REMAN/REFILLED)
HP DJ F4280 Colour	HP 300 / CC642EE Colour INTRO (REMAN/REFILLED)
HP DJ F4280 Colour	HP 300 / CC643EE Colour (REMAN/REFILLED)
HP DJ F4280 Black	HP 300XL / CC641EE Black (REMAN/REFILLED)
HP DJ F4280 Colour	HP 300XL / CC644EE Colour (REMAN/REFILLED)
HP DeskJet 1000/1050/2050/2510/3000/3050/3055A	HP 301 / CH561EE Black (REMAN/REFILLED)
HP DeskJet 1000/1050/2050/2510/3000/3050/3055A	HP 301 / CH562EE Colour (REMAN/REFILLED)
HP Deskjet 1010/1510/12/14/2512/40/42/44/49/Envy 4500 Series	HP 301 / CH561EE Black (REMAN/REFILLED)
HP Deskjet 1010/1510/12/14/2512/40/42/44/49/Envy 4500 Series	HP 301 / CH562EE Colour (REMAN/REFILLED)
HP DeskJet 1000/1050/2050/2510/3000/3050/3055A	HP 301XL / CH563EE Black (REMAN/REFILLED)
HP DeskJet 1000/1050/2050/2510/3000/3050/3055A	HP 301XL / CH564EE Colour (REMAN/REFILLED)
HP Deskjet 1010/1510/12/14/2512/40/42/44/49/Envy 4500 Series	HP 301XL / CH563EE Black (REMAN/REFILLED)
HP Deskjet 1010/1510/12/14/2512/40/42/44/49/Envy 4500 Series	HP 301XL / CH564EE Colour (REMAN/REFILLED)
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Black / F6U66AE (REMAN/REFILLED)
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Black XL / F6U68AE (REMAN/REFILLED)
HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Colour / F6U65AE (REMAN/REFILLED)

HP Deskjet 1110/2130/3630/Envy 4520/4522/4523/4524/Officejet 38	HP 302 Colour XL / F6U67AE (REMAN/REFILLED)
HP Deskjet 3720/3730/3732/3733	HP 304 Black / N9K06AE (REMAN/REFILLED)
HP Deskjet 3720/3730/3732/3733	HP 304XL Black / N9K08AE (REMAN/REFILLED)
HP Deskjet 3720/3730/3732/3733	HP 304 Colour / N9K05AE (REMAN/REFILLED)
HP Deskjet 3720/3730/3732/3733	HP 304XL Colour / N9K07AE (REMAN/REFILLED)
HP Deskjet 3720/3730/3732/3733	HP 304 Black (NOT SETUP H)
HP Deskjet 3720/3730/3732/3733	HP 304 Colour (NOT SETUP H)
HP DJ 5400 Series Low Black	HP 336 / C9362EE Black (REMAN/REFILLED)
HP Photosmart 2570 Fast Black	HP 337 / C9364EE Black (REMAN/REFILLED)
HP DJ 5740/6520/6540/6540dt/6840 Black	HP 338 / C8765E Black (REMAN/REFILLED)
HP DJ 5740/6520/6540/6540dt/6840 High Black	HP 339 / C8767E Black (REMAN/REFILLED)
HP DJ 5400 Series Low Colour	HP 342 / C9361EE Colour (REMAN/REFILLED)
HP DJ 5740/6520/6540/6540dt/6840 Colour	HP 343 / C8766EE Colour (REMAN/REFILLED)
HP DJ 5740/6520/6540/6540dt/6840 High Colour	HP 344 / C9363E Colour (REMAN/REFILLED)
HP DJ 5740/6520/6540/6540dt/6840	HP 348 / C9369EE Photo
HP DJ D4260/OfficeJet J5780 Black	HP 350 / CB335EE Black (REMAN/REFILLED)
HP DJ D4260/OfficeJet J5780 High Black	HP 350XL / CB336EE Black (REMAN/REFILLED)
HP DJ D4260/OfficeJet J5780 Colour	HP 351 / CB337EE Colour (REMAN/REFILLED)
HP DJ D4260/OfficeJet J5780 High Colour	HP 351XL / CB338EE Colour (REMAN/REFILLED)
HP 700 / 800 / 1000 / 1100 / 1600 series (black)	HP 45 / 51645 Black (REMAN/REFILLED)
HP DJ 420ci/cbi/5150/5550c/5552 Black	HP 56 / C6656A Black (REMAN/REFILLED)
HP DJ 420ci/cbi/5150/5550c/5552 Colour	HP 57 / C6657A Colour (REMAN/REFILLED)
HP Envy 5640 e-All-in-One / 7640 / Officejet 5740	HP 62 / C2P04A Black (REMAN/REFILLED)
HP Envy 5640 e-All-in-One / 7640 / Officejet 5740	HP 62XL / C2P05A Black (REMAN/REFILLED)
HP Envy 5640 e-All-in-One / 7640 / Officejet 5740	HP 62 / C2P06A Colour (REMAN/REFILLED)
HP Envy 5640 e-All-in-One / 7640 / Officejet 5740	HP 62XL / C2P07A Colour (REMAN/REFILLED)
HP Deskjet Ink Advantage 2515 and 2515 e-All-in-One	HP 650 / CZ101AE Black
HP Deskjet Ink Advantage 2515 and 2515 e-All-in-One	HP 650 / CZ102AE Colour
HP Fax 640 printer	HP 701 / CC635A Black (REMAN/REFILLED)
HP DeskJet 930/950/970/980/990/G55/G85/G95	HP 77XL / CB277A Colour
HP Officejet G55 / 85 / 95 (tri Colour cartridge)	HP 78 / C6578 Colour (REMAN/REFILLED)
HP Officejet G55 / 85 / 95 (tri Colour cartridge)	HP 78 / C6578 Colour (REMAN/REFILLED)
HP OfficeJet J4580 / J4660 / 4680 Black	HP 901 / CC563AE Black (REMAN/REFILLED)
HP OfficeJet J4580 / J4660 / 4680 Colour	HP 901 / CC656AE Colour (REMAN/REFILLED)
HP OfficeJet J4580 / J4660 / 4680 Black	HP 901XL / CC654AE Black (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 / T6L99AE Black (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 / T6L87AE Cyan (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 / T6L91AE Magenta (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903 / T6L95AE Yellow (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903XL / T6M15AE Black (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903XL / T6M03AE Cyan (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903XL / T6M07AE Magenta (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 903XL / T6M11AE Yellow (REMAN/REFILLED)
HP Officejet Pro 6950/6960/6970/6975 All-in-One	HP 907XL / T6M19AE Black (REMAN/REFILLED)
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 / L0S58AE Black
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 / F6U12AE Cyan
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 / F6U13AE Magenta
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 / F6U14AE Yellow
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953XL / L0S70AE Black
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953XL / F6U16AE Cyan
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953XL / F6U17AE Magenta
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953XL / F6U18AE Yellow
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 Black INTRO
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 Cyan INTRO
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 Magenta INTRO
HP Officejet Pro 7740/8210/18/8710/15/16/18/20/25/28/30/40	HP 953 Yellow INTRO
Lexmark Inkjet Printers	Lexmark Inkjet Printers
Lexmark X2310/2330/2350/Z730/735	Lexmark 1 / 18C0781 Colour
Lexmark 100 / 14N0820E Black	Lexmark 100 / 14N0820E Black
Lexmark 100 / 14N0900E Cyan	Lexmark 100 / 14N0900E Cyan
Lexmark 100 / 14N0901E Magenta	Lexmark 100 / 14N0901E Magenta

Lexmark 100 / 14N0902E Yellow	Lexmark 100 / 14N0902E Yellow
Lexmark 100XL / 14N1068 Black	Lexmark 100XL / 14N1068 Black
Lexmark 100XL / 14N1069E Cyan	Lexmark 100XL / 14N1069E Cyan
Lexmark 100XL / 14N1070E Magenta	Lexmark 100XL / 14N1070E Magenta
Lexmark 100XL / 14N1071E Yellow	Lexmark 100XL / 14N1071E Yellow
Lexmark 4076/1000/20/100/2030/50/55	Lexmark 13400HC Black
Lexmark i3/Z13/Z23/Z33/Z601/Z605 Black	Lexmark 16 / 10N0016 Black
Lexmark Z35/Z601/Z605 Low Black	Lexmark 17 / 10N0217 Black
Lexmark X2580/3580/Z1380 Colour	Lexmark 2 / 18C0190 Colour
Lexmark i3/Z13/Z23/Z33/Z601/Z605 Colour	Lexmark 26 / 10N0026 Colour
Lexmark X2580/3580/Z1380 Black	Lexmark 3 / 18C1530 Black
Lexmark Z815/X5250/5270 Photo Colour	Lexmark 31 / 18C0031 Photo
Lexmark Z815/X5250/5270 Black	Lexmark 32 / 18C0032 Black
Lexmark Z815/X5250/5270 Colour	Lexmark 33 / 18C0033 Colour
Lexmark Z815/X5250/5270 Black	Lexmark 34 / 18C0034 Black
Lexmark Z815/X5250/5270 Black	Lexmark 34XL / 18C0034 Black
Lexmark (various models)	Lexmark 35 / 18C0035 Colour
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650 Blac	Lexmark 36A / 18C2150E Black
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650 Blac	Lexmark 36XL / 18C2170E Black
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650 Blac	Lexmark 36XLA / 18C2190E Black
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650 Colo	Lexmark 37A / 18C2160E Colour
Lexmark X4800/6570 Colour	Lexmark 41A / 18Y0341E Colour
Lexmark X4800/6570 Black	Lexmark 42A / 18Y0342E Black
Lexmark X9350 / P350 Colour	Lexmark 43 / 18Y0143 Colour
Lexmark X9350 / P350 Colour	Lexmark 43XL / 18Y0133 Colour
Lexmark X9350	Lexmark 44 / 18Y0144 Black
Lexmark X9350 Black	Lexmark 44XL / 18Y0134 Black

Remanufactured / Refilled Lexmark Inkjet Printers	Remanufactured / Refilled Lexmark Inkjet Printers
---	---

Lexmark 4076/1000/20/100/2030/50/55	Lexmark 13400HC (REMAN/REFILLED)
Lexmark i3/Z13/Z23/Z33/Z601/Z605 Black	Lexmark 16 / 10N0016 Black (REMAN/REFILLED)
Lexmark Z35/Z601/Z605 Low Black	Lexmark 17 / 10N0217 Black (REMAN/REFILLED)
Lexmark X2580/3580/Z1380 Black	Lexmark 3 / 18C1530 Black (REMAN/REFILLED)
Lexmark Z815/X5250/5270 Black	Lexmark 34 / 18C0034 Black (REMAN/REFILLED)
Lexmark (various models)	Lexmark 35 / 18C0035 Colour (REMAN/REFILLED)
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650	Lexmark 36A / 18C2150E Black (REMAN/REFILLED)
Lexmark Z2400, Z2410, Z2420, X3630, X3650, X4630, X4650	Lexmark 37A / 18C2160E Colour (REMAN/REFILLED)

Samsung Inkjet Printers	Samsung Inkjet Printers
-------------------------	-------------------------

Samsung SF-4000 / 4100 / 4200 / 3000 / 3100 / 3200	Samsung INK-M10
Samsung SF-300/300T/330/331P/335T/340/341P/345TP/355T/360/3	Samsung INK-M40 Black
Samsung SF-300/300T/330/331P/335T/340/341P/345TP/355T/360/3	Samsung INK-M40 Black INTRO
Samsung SF370 / SF375TP	Samsung INK-M41 Black
Samsung SF370 / SF375TP	Samsung INK-M41 Black INTRO
Samsung SF350 Fax machine	Samsung INK-M55

Remanufactured / Refilled Samsung Inkjet Printers	Remanufactured / Refilled Samsung Inkjet Printers
---	---

Samsung SF330 / SF335T / SF331P	Samsung INK-M40 Black (REMAN/REFILLED)
Samsung SF370 / SF375TP	Samsung INK-M41 Black (REMAN/REFILLED)

Misc Inkjet Printers	Misc Inkjet Printers
----------------------	----------------------

All Kodak Cartridges (ALL OEM\ORIGINAL)	All Kodak Cartridges (ALL OEM\ORIGINAL)
HP Inkjet Cartridge No Value	HP Inkjet Cartridge No Value
Neopost IJ 25	Neopost IJ 25 Red
Neopost RJ 25	Neopost IJ 25 Blue
Neopost RJ 35 (410)	Neopost RJ 35 (410)
Neopost RJ 35 (413)	Neopost RJ 35 (413)
Neopost RJ 35 (4135555U)	Neopost RJ 35 (4135555U)
Neopost RJ 35 (412)	Neopost RJ 35 (412)
Neopost RJ 35 (414)	Neopost RJ 35 (414)
Neopost IJ 240 Blue	Neopost IJ 240 Blue
Neopost IJ 240 Red	Neopost IJ 240 Red
HP C6120A Red Fluorescent	HP C6120A Red Fluorescent
HP C6128A Red	HP C6128A Red

HP C6170A Blue	HP C6170A Blue
HP C8842A Versatile black	HP C8842A Versatile black
HP CG401A Blue (Must have plug on bottom)	HP CG401A Blue
HP Q2344A Black (Must have plug on bottom)	HP Q2344A Black (1918)
HP Q2353A Blue (Must have plug on bottom)	HP Q2353A Blue
HP Q2354A Blue (Must have plug on bottom)	HP Q2354A Blue
Frama Matrix F2/F4/F6/F8/F12/F22/F32/F42/F62/F82	Frama Matrix All Colours
HP C6120A Red Fluorescent	HP C6120A Red Fluorescent
HP C6128A Red	HP C6128A Red
HP C6170A Blue	HP C6170A Blue
HP C8842A Versatile black	HP C8842A Versatile black
HP CG401A Blue (Must have plug on bottom)	HP CG401A Blue
HP Q2344A Black (Must have plug on bottom)	HP Q2344A Black (1918)
HP Q2353A Blue (Must have plug on bottom)	HP Q2353A Blue
HP Q2354A Blue (Must have plug on bottom)	HP Q2354A Blue
Sharp UXB20 / UXB30 / UXB700 / UXBD80 / UXBS60	Sharp UX-C70B Black

Brother Fax & Laser Printers	Brother Fax & Laser Printers
Brother DCP-1510 / HL-1110 / HL-1112 / MFC-1810	Brother DR-1050 / DR1030 Drum
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother DR-130CL / 135CL Drum
Brother HL-2035 / 2045	Brother DR-2005 Drum
Brother HL-2140/2150N/2170W	Brother DR-2100 / DR-360 Drum
Brother DCP-7055 / HL-2130 / HL-2132 / HL-2135	Brother DR-2200 Drum
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother DR-230 Black Drum
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother DR-230 CMY Drum
Brother DCP-L2500D/L2520DW/L2540DN/HL-L2300D/L2340DW/L2360DN/L2365DW/MF	Brother DR-2300 Drum
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother DR-241 Black Drum
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother DR-241CL Drum
Brother DCP-8060/8065/HL-5240/HL-5250/5270/5280DW/MFC-8460/8860/8870	Brother DR-3100 / DR520 Drum
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother DR-320CL Drum
Brother DCP-L8400/8450/8250/HL-L8350/9200/9300/MFC-L8650/8850/9550	Brother DR-321CL Drum
Brother DCP-8070/8085/HL-5340/5350/5370/5380/MFC-8370/8380/8880/8890	Brother DR-3200 / DR620 Drum
Brother DCP-8110/8250/HL-5440/5450/5470/6180/MFC-8510/8520/8950	Brother DR-3300 Drum
Brother DCP-L5500/6600/HL-L5000/5100/5200/6300/6400/MFC-L5700/5750/6800/6900/	Brother DR-3400 Drum
Brother DCP-1510 / HL-1110 / HL-1112 / MFC-1810	Brother TN-1050
Brother DCP-1510 / HL-1110 / HL-1112 / MFC-1810	Brother TN-1050 INTRO
Brother HL-1110/1112/1210/1212/MFC-1810/1815/DCP-1510/1512/1910	Brother TN-1060
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother TN-130 Black Std Cap
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother TN-130 Cyan Std Cap
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother TN-130 Magenta Std Cap
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother TN-130 Yellow Std Cap
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother TN-135 Black Hi Cap
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother TN-135 Cyan Hi Cap
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother TN-135 Magenta Hi Cap
Brother DCP-9040/9042/9045/HL-4040/4050/4070/MFC-9440/9450/9840	Brother TN-135 Yellow Hi Cap
Brother HL-1700/8050	Brother TN-1700 Black
Brother DCP-7010/7020/7025/FAX-2820/2920/HL-2030/2040/2050/2070/MFC-7225N/7420/	Brother TN-2000 / TN350
Brother DCP-7010/7020/7025/FAX-2820/2920/HL-2030/2040/2050/2070/MFC-7225N/7420/	Brother TN-2000 / TN350 INTRO
Brother HL-2035 / 2045	Brother TN-2005
Brother HL-2035 / 2045	Brother TN-2005 INTRO
Brother DCP-7055 / HL-2130 / HL-2132 / HL-2135	Brother TN-2010
Brother DCP-7055 / HL-2130 / HL-2132 / HL-2135	Brother TN-2010 INTRO
Brother HL-2140/2150N/2170W	Brother TN-2110
Brother HL-2140/2150N/2170W	Brother TN-2110 / TN2120 INTRO
Brother HL-2140/2150N/2170W	Brother TN-2120
Brother DCP7040/HL2140/HL2142/HL2150N/HL2170W/MFC7340/MFC7440/MFC7840W	Brother TN-2130
Brother DCP7040/HL2140/HL2142/HL2150N/HL2170W/MFC7340/MFC7440/MFC7840W	Brother TN-2150
Brother HL-2240 / 2250 / 2270	Brother TN-2210 / TN-420
Brother HL-2240 / 2250 / 2270	Brother TN-2210 / TN-2220 INTRO
Brother HL-2240 / 2250 / 2270	Brother TN-2220 / TN-450 Hi Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother TN-230 Black Hi Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother TN-230 Cyan Hi Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother TN-230 Magenta Hi Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother TN-230 Yellow Hi Cap
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother TN-230 Black INTRO
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother TN-230 Cyan INTRO
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother TN-230 Magenta INTRO
Brother HL3040CN / HL3070CW / DCP9010 / MFC9120CN / MFC9320CW	Brother TN-230 Yellow INTRO
Brother DCP-L2500D/L2520DW/L2540DN/HL-L2300D/L2340DW/L2360DN/L2365DW/MF	Brother TN-2310
Brother DCP-L2500D/L2520DW/L2540DN/HL-L2300D/L2340DW/L2360DN/L2365DW/MF	Brother TN-2320
Brother DCP-L2500D/L2520DW/L2540DN/HL-L2300D/L2340DW/L2360DN/L2365DW/MF	Brother TN-2310 / TN-2320 INTRO
Brother DCP-9010CN/HL-3040CN/3045/3070CW/3075/MFC-9120CN/9125/9320CW/9325	Brother TN-240 Black
Brother DCP-9010CN/HL-3040CN/3045/3070CW/3075/MFC-9120CN/9125/9320CW/9325	Brother TN-240 Cyan
Brother DCP-9010CN/HL-3040CN/3045/3070CW/3075/MFC-9120CN/9125/9320CW/9325	Brother TN-240 Magenta
Brother DCP-9010CN/HL-3040CN/3045/3070CW/3075/MFC-9120CN/9125/9320CW/9325	Brother TN-240 Yellow
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 Black
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 Cyan
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 Magenta
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 Yellow
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 / 245 Black INTRO
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 / 245 Cyan INTRO
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 / 245 Magenta INTRO
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 / 245 Yellow INTRO
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-242 Black
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-242 Cyan
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-242 Magenta
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-242 Yellow
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-242 / 246 Black INTRO
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-242 / 246 Cyan INTRO

Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-242 / 246 Magenta INTRO
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-242 / 246 Yellow INTRO
Brother DCP-9020CDW/HL-3140/3150/3170/MFC-9140/9330/9340c	Brother TN-245 Cyan
Brother DCP-9020CDW/HL-3140/3150/3170/MFC-9140/9330/9340c	Brother TN-245 Magenta
Brother DCP-9020CDW/HL-3140/3150/3170/MFC-9140/9330/9340c	Brother TN-245 Yellow
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-246 Cyan
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-246 Magenta
Brother DCP-9017/9022/3142/3152/3172/9142/9332/9342	Brother TN-246 Yellow
Brother DCP-8040/8045D/HL-5130/5140/5150/5170dn/MFC-8440	Brother TN-3030 / TN540
Brother DCP-8040/8045D/HL-5130/5140/5150/5170dn/MFC-8440	Brother TN-3060 / TN570
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-310 Black
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-310 Cyan
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-310 Magenta
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-310 Yellow
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-315 Black
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-315 Cyan
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-315 Magenta
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-315 Yellow
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-310 / TN-315 Black INTRO
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-310 / TN-315 Cyan INTRO
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-310 / TN-315 Magenta INTRO
Brother DCP-9055CDN/HL-4140CN/4150CDN/4150CSN/4570CDW/4570CDWT/MFC-9460	Brother TN-310 / TN-315 Yellow INTRO
Brother DCP-8060/8065/HL-5240/HL-5250/5270/5280DW/MFC-8460/8860/8870	Brother TN-3130 / TN550
Brother DCP-8060/8065/HL-5240/HL-5250/5270/5280DW/MFC-8460/8860/8870	Brother TN-3170 / TN580
Brother DCP-8060/8065/HL-5240/HL-5250/5270/5280DW/MFC-8460/8860/8871	Brother TN-3130 / TN-3170 INTRO
Brother HL-5240/5250DN/5270DN/MFC-8460N/8860DN	Brother TN-3185 Hi Cap Black
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-320 / TN-325 / TN-328 Black INTRO
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-320 / TN-325 / TN-328 Cyan INTRO
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-320 / TN-325 / TN-328 Magenta INTRO
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-320 / TN-325 / TN-328 Yellow INTRO
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-320 Black Std Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-320 Cyan Std Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-320 Magenta Std Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-320 Yellow Std Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-321 Black Std Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-321 Cyan Std Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-321 Magenta Std Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-321 Yellow Std Cap
Brother DCP-8070/8085/HL-5340/5350/5370/5380/MFC-8370/8380/8880/8890	Brother TN-3230 / TN620
Brother DCP-8070/8085/HL-5340/5350/5370/5380/MFC-8370/8380/8880/8891	Brother TN-3230 / TN-3280 INTRO
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-325 Black Hi Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-325 Cyan Hi Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-325 Magenta Hi Cap
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother TN-325 Yellow Hi Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-326 Black Hi Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-326 Cyan Hi Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-326 Magenta Hi Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-326 Yellow Hi Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-321 / TN-326 Black INTRO
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-321 / TN-326 Cyan INTRO
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-321 / TN-326 Magenta INTRO
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-321 / TN-326 Yellow INTRO
Brother DCP-9270CDN / HL-4570CDWT	Brother TN-328 Black HC
Brother DCP-9270CDN / HL-4570CDWT	Brother TN-328 Cyan HC
Brother DCP-9270CDN / HL-4570CDWT	Brother TN-328 Magenta HC
Brother DCP-9270CDN / HL-4570CDWT	Brother TN-328 Yellow HC
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-329 Black Ex Hi Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-329 Cyan Ex Hi Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-329 Magenta Ex Hi Cap
Brother DCP-L8400CDN/L8450CDW/HL-L8250CDN/L8350CDW/MFC-L8650CDW/L8850	Brother TN-329 Yellow Ex Hi Cap
Brother DCP-8070/8085/HL-5340/5350/5370/5380/MFC-8370/8380/8880/8890	Brother TN-3280 / TN650
Brother DCP-8110/8250/HL-5440/5450/5470/6180/MFC-8510/8520/8950	Brother TN-3330
Brother DCP-8110/8250/HL-5440/5450/5470/6180/MFC-8510/8520/8950	Brother TN-3330 / TN-3380 / TN-3390 INTRO
Brother DCP-8110/8250/HL-5440/5450/5470/6180/MFC-8510/8520/8950	Brother TN-3380
Brother DCP-8250DN / HL-6180DW / 6180DWT / MFC-8950DWT	Brother TN-3390
Brother DCP-L5500/6600/HL-L5000/5100/5200/6300/6400/MFC-L5700/5750/6800/6900/	Brother TN-3430
Brother DCP-L5500/6600/HL-L5000/5100/5200/6300/6400/MFC-L5700/5750/6800/6900/	Brother TN-3480
Brother DCP-L5500/6600/HL-L5000/5100/5200/6300/6400/MFC-L5700/5750/6800/6900/	Brother TN-3430/3480 INTRO
Brother DCP9055CDN/HL4150CDN/HL4570CDW/MFC9460CDN/MFC9970CDW	Brother TN-348 Black Hi Cap
Brother DCP9055CDN/HL4150CDN/HL4570CDW/MFC9460CDN/MFC9970CDW	Brother TN-348 Cyan Hi Cap
Brother DCP9055CDN/HL4150CDN/HL4570CDW/MFC9460CDN/MFC9970CDW	Brother TN-348 Magenta Hi Cap
Brother DCP9055CDN/HL4150CDN/HL4570CDW/MFC9460CDN/MFC9970CDW	Brother TN-348 Yellow Hi Cap

Brother HL-6050 Series	Brother TN-4100 / TN670
Brother FAX-8650P/ 8750P/9650/9750/9870	Brother TN-6300 / TN430
Brother FAX-8650P/ 8750P/9650/9750/9870	Brother TN-6600 / TN460
Brother HL-1650 / HL - 1670N	Brother TN-7300 / TN530
Brother HL-1650 / HL - 1670N	Brother TN-7600 / TN560
Brother HL-L9200CDWT/HL-L9300CDWT/MFC-L9550CDWT	Brother TN-900 Black
Brother HL-L9200CDWT/HL-L9300CDWT/MFC-L9550CDWT	Brother TN-900 Cyan
Brother HL-L9200CDWT/HL-L9300CDWT/MFC-L9550CDWT	Brother TN-900 Magenta
Brother HL-L9200CDWT/HL-L9300CDWT/MFC-L9550CDWT	Brother TN-900 Yellow
Brother HL-L9200CDWT/HL-L9300CDWT/MFC-L9550CDWT	Brother TN-900 Black INTRO
Brother HL-L9200CDWT/HL-L9300CDWT/MFC-L9550CDWT	Brother TN-900 Cyan INTRO
Brother HL-L9200CDWT/HL-L9300CDWT/MFC-L9550CDWT	Brother TN-900 Magenta INTRO
Brother HL-L9200CDWT/HL-L9300CDWT/MFC-L9550CDWT	Brother TN-900 Yellow INTRO
Remanufactured / Refilled Brother Laser Printers	Remanufactured / Refilled Brother Laser Printers
Brother DCP-1510 / HL-1110 / HL-1112 / MFC-1810	Brother DR-1050 Drum (REMAN)
Brother DCP-L2500D/L2520DW/L2540DN/HL-L2300D/L2340DW/L2360DN/L2365DW/MF	Brother DR-2300 Drum (REMAN)
Brother DCP-9055CDN / HL-4140 / 4150 / 4570 / MFC-9460 / 9465 / 9970	Brother DR-320CL Drum (REMAN)
Brother DCP-L8400/8450/8250/HL-L8350/9200/9300/MFC-L8650/8850/9550	Brother DR-321CL Drum (REMAN)
Brother DCP-8070/8085/HL-5340/5350/5370/5380/MFC-8370/8380/8880/8890	Brother DR-3200 / DR620 Drum (REMAN)
Brother DCP-8110/8250/HL-5440/5450/5470/6180/MFC-8510/8520/8950	Brother DR-3300 Drum (REMAN)
Brother DCP-L5500/6600/HL-L5000/5100/5200/6300/6400/MFC-L5700/5750/6800/6900/	Brother DR-3400 Drum
Brother HL-2030 / 2040	Brother TN-2000 / TN350 (REMAN)
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 Black (REMAN)
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 Cyan (REMAN)
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 Magenta (REMAN)
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 Yellow (REMAN)
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 / 245 Black INTRO (REMAN)
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 / 245 Cyan INTRO (REMAN)
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 / 245 Magenta INTRO (REMAN)
Brother HL3140 / HL3170 / MFC9130 / MFC9330	Brother TN-241 / 245 Yellow INTRO (REMAN)
Brother DCP-9020CDW/HL-3140/3150/3170/MFC-9140/9330/9340c	Brother TN-245 Cyan (REMAN)
Brother DCP-9020CDW/HL-3140/3150/3170/MFC-9140/9330/9340c	Brother TN-245 Magenta (REMAN)
Brother DCP-9020CDW/HL-3140/3150/3170/MFC-9140/9330/9340c	Brother TN-245 Yellow (REMAN)
Brother TN3330	Brother TN-3330 (REMAN)
Brother DCP-8110/8250/HL-5440/5450/5470/6180/MFC-8510/8520/8950	Brother TN-3330 / 80 / 90 INTRO (REMAN)
Brother TN3330	Brother TN-3380 (REMAN)
Brother DCP-L5500/6600/HL-L5000/5100/5200/6300/6400/MFC-L5700/5750/6800/6900/	Brother TN-3430
Brother DCP-L5500/6600/HL-L5000/5100/5200/6300/6400/MFC-L5700/5750/6800/6900/	Brother TN-3480
Canon Fax & Laser Printers	Canon Fax & Laser Printers
Canon I-SENSYS LBP-6000	Canon 725
Canon I-SENSYS LBP-6000	Canon 725 INTRO
Canon LBP6200d	Canon 726
Canon LBP6200d	Canon 726 INTRO
Canon I-SENSYS MF4410 / MF4430 / MF4450 / MF4580dn / MF4570dn	Canon 728
Canon I-SENSYS MF4410 / MF4430 / MF4450 / MF4580dn / MF4570dn	Canon 728 INTRO
Canon FC1 / FC2 / FC3 / FC3II / FC5 / FC5II / PC11 / PC6 / PC7 / PC7RE	Canon A30
Canon IR-2270 Black	Canon C-EXV 11 Black
Canon IR-3570 Black	Canon C-EXV 12 Black
Canon IR-2016/2018/2020/2022/2025/2030/2320/2420/2422	Canon C-EXV 14 Black
Canon C-EXV15 Black	Canon C-EXV 15 Black
Canon C-EXV18 Black	Canon C-EXV 18 Black
Canon IR-C5235i / C5240i / C5250 / C5255 / C5045 / C5051i	Canon C-EXV 28 Black
Canon IR-C5235i / C5240i / C5250 / C5255 / C5045 / C5051i	Canon C-EXV 28 Cyan
Canon IR-C5235i / C5240i / C5250 / C5255 / C5045 / C5051i	Canon C-EXV 28 Magenta
Canon IR-C5235i / C5240i / C5250 / C5255 / C5045 / C5051i	Canon C-EXV 28 Yellow
Canon IR-C5030 / C5035 / C5240i / C5250 / C5255	Canon C-EXV 29 Black
Canon IR-C5030 / C5035 / C5240i / C5250 / C5255	Canon C-EXV 29 Cyan
Canon IR-C5030 / C5035 / C5240i / C5250 / C5255	Canon C-EXV 29 Magenta
Canon IR-C5030 / C5035 / C5240i / C5250 / C5255	Canon C-EXV 29 Yellow
Canon IR C7055 / C7065 / C7260i / C7270i / C7280i	Canon C-EXV 31 Black
Canon IR C7055 / C7065 / C7260i / C7270i / C7280i	Canon C-EXV 31 Cyan
Canon IR C7055 / C7065 / C7260i / C7270i / C7280i	Canon C-EXV 31 Magenta
Canon IR C7055 / C7065 / C7260i / C7270i / C7280i	Canon C-EXV 31 Yellow
Canon IR 2535 / IR2545i	Canon C-EXV 32 Black
Canon IR 2520 / IR 2525 / IR 2530i	Canon C-EXV 33 Black
Canon IR-C2020 / C2030	Canon C-EXV 34 Black
Canon IR-C2020 / C2030	Canon C-EXV 34 Cyan
Canon IR-C2020 / C2030	Canon C-EXV 34 Magenta
Canon IR-C2020 / C2030	Canon C-EXV 34 Yellow
Canon IR-1730i / IR-1740i / IR-1750i	Canon C-EXV 35 Black
Canon IR-6055/6055/6065/6075/6255/6265/6275/6555/6565/6571	Canon C-EXV 36 Black
Canon IR-1730/1740/1750	Canon C-EXV 37 Black

Canon IR 4045i / IR4051i	Canon C-EXV 38 Black
Canon IR-4025/4035/4225/4235/4245/4251	Canon C-EXV 39 Black
Canon IR-400/500	Canon C-EXV 43 Black
Canon IR-9200/9280/9200/9270/9280	Canon C-EXV 44 Black
Canon IR-9200/9280/9200/9270/9280	Canon C-EXV 44 Cyan
Canon IR-9200/9280/9200/9270/9280	Canon C-EXV 44 Magenta
Canon IR-9200/9280/9200/9270/9280	Canon C-EXV 44 Yellow
Canon IR-C7260i/7270/7280	Canon C-EXV 45 Black
Canon IR-C7260i/7270/7280	Canon C-EXV 45 Cyan
Canon IR-C7260i/7270/7280	Canon C-EXV 45 Magents
Canon IR-C7260i/7270/7280	Canon C-EXV 45 Yellow
Canon IR C250i/C350i/C350P/IR C351iF	Canon C-EXV 47 Black
Canon IR C250i/C350i/C350P/IR C351iF	Canon C-EXV 47 Cyan
Canon IR C250i/C350i/C350P/IR C351iF	Canon C-EXV 47 Magenta
Canon IR C250i/C350i/C350P/IR C351iF	Canon C-EXV 47 Yellow
Canon IR C1325iF/C1335iF/C1335iFC	Canon C-EXV 48 Black
Canon IR C1325iF/C1335iF/C1335iFC	Canon C-EXV 48 Cyan
Canon IR C1325iF/C1335iF/C1335iFC	Canon C-EXV 48 Magenta
Canon IR C1325iF/C1335iF/C1335iFC	Canon C-EXV 48 Yellow
Canon IR-C3320 / C3325 / C3330	Canon C-EXV 49 Black
Canon IR-C3320 / C3325 / C3330	Canon C-EXV 49 Cyan
Canon IR-C3320 / C3325 / C3330	Canon C-EXV 49 Magenta
Canon IR-C3320 / C3325 / C3330	Canon C-EXV 49 Yellow
Canon FC200 / 300 series / PC300 / 500 / 700 series	Canon E30 / E15 Japan / Chinese Versions
Canon FC200 / 300 series / PC300 / 500 / 700 series	Canon E30 / E15 French or Others
Canon LBP3200/300N/LDA/LDF Black	Canon EP-27
Canon LBP910	Canon CRG-H
Canon LBP 3300 / 3360	Canon EP-508 Std Cap
Canon L 100 / 120 Fax	Canon FX10
Remanufactured / Refilled Canon Laser Printers	Remanufactured / Refilled Canon Laser Printers
Dell Printers	Dell Printers
Dell 1130, 1130n, 1133, 1135n	Dell 113X / 2MMJP Hi Cap
Dell 1130, 1130n, 1133, 1135n	Dell 113X / 3J11D Std Cap
Dell 1250c / 1350cnw / 1355cn / 1355cnw	Dell 1250 / 1350 / 1355 Black Hi Cap
Dell 1250c / 1350cnw / 1355cn / 1355cnw	Dell 1250 / 1350 / 1355 Cyan Hi Cap
Dell 1250c / 1350cnw / 1355cn / 1355cnw	Dell 1250 / 1350 / 1355 Magenta Hi Cap
Dell 1250c / 1350cnw / 1355cn / 1355cnw	Dell 1250 / 1350 / 1355 Yellow Hi Cap
Dell 1250c / 1350cnw / 1355cn / 1355cnw	Dell 1250 / 1350 / 1355 Black Std Cap
Dell 1250c / 1350cnw / 1355cn / 1355cnw	Dell 1250 / 1350 / 1355 Cyan Std Cap
Dell 1250c / 1350cnw / 1355cn / 1355cnw	Dell 1250 / 1350 / 1355 Magenta Std Cap
Dell 1250c / 1350cnw / 1355cn / 1355cnw	Dell 1250 / 1350 / 1355 Yellow Std Cap
Dell 1260 / 1265	Dell 1260 / 1265 DRYXV Hi Cap
Dell 1260 / 1265	Dell 1260 / 1265 G9W85 Std Cap
Dell P1600	Dell 1600N ALL
Dell 1815dn	Dell 1815 NF485 Std Cap
Dell 1815dn	Dell 1815 RF223 Hi Cap
Dell 2230	Dell 2230 / M797K & M795K
Dell 2330d / 2330dn / 2350d / 2350dn	Dell 2330DN ALL
Dell 2335	Dell 2335 Std Cap
Dell 2335	Dell 2335 / HX756 HI CAP
Dell 2355	Dell 2355 Std Cap
Dell 2355	Dell 2355 Hi Cap
Dell 3110CN / 3115CN (Epson C2800 / Xerox 6180)	Dell 3110 / 3115 PF028 Black Std Cap
Dell 3110CN / 3115CN (Epson C2800 / Xerox 6180)	Dell 3110 / 3115 RF012 Cyan Std Cap
Dell 3110CN / 3115CN (Epson C2800 / Xerox 6180)	Dell 3110 / 3115 MF790 Magenta Std Cap
Dell 3110CN / 3115CN (Epson C2800 / Xerox 6180)	Dell 3110 / 3115 NF555 Yellow Std Cap
Dell 3110CN / 3115CN (Epson C2800 / Xerox 6180)	Dell 3110 / 3115 PF030 Black Hi Cap
Dell 3110CN / 3115CN (Epson C2800 / Xerox 6180)	Dell 3110 / 3115 PF029 Cyan Hi Cap
Dell 3110CN / 3115CN (Epson C2800 / Xerox 6180)	Dell 3110 / 3115 MW566 Magenta Hi Cap
Dell 3110CN / 3115CN (Epson C2800 / Xerox 6180)	Dell 3110 / 3115 NF556 Yellow Hi Cap
Dell 3130	Dell 3130 Black Hi Cap
Dell 3130	Dell 3130 Cyan Hi Cap
Dell 3130	Dell 3130 Magenta Hi Cap
Dell 3130	Dell 3130 Yellow Hi Cap
Dell 3130	Dell 3130 Black Std Cap
Dell 3130	Dell 3130 Cyan Std Cap
Dell 3130	Dell 3130 Magenta Std Cap
Dell 3130	Dell 3130 Yellow Std Cap
Dell 3330	Dell 3330 / P976R
Dell 3333DN / 3335DN	Dell 3333DN / 3335DN Hi Cap
Dell 3333DN / 3335DN	Dell 3333DN / 3335DN Std Cap
Dell 5130	Dell 5130 Black

Dell 5130	Dell 5130 Cyan
Dell 5130	Dell 5130 Magenta
Dell 5130	Dell 5130 Yellow
Dell 7130 Black	Dell 7130 Black
Dell 7130 Cyan	Dell 7130 Cyan
Dell 7130 Magenta	Dell 7130 Magenta
Dell 7130 Yellow	Dell 7130 Yellow
Dell 5350dn	Dell 5230/5320/5350 ALL Black
Dell B1160 / B1160w / B1163w / B1165nfw	Dell B116 Hi Cap
Dell B1160 / B1160w / B1163w / B1165nfw	Dell B116 Std Cap
Dell B1160 / B1160w / B1163w / B1165nfw	Dell B116 INTRO
Dell B1260dn / B1265dfw / B1265dnf	Dell B126 / DRYXV HI Cap
Dell B1260dn / B1265dfw / B1265dnf	Dell B126 / G9W85 Std Cap
Dell B1260dn / B1265dfw / B1265dnf	Dell B126 INTRO
Dell B2360D / B3460DN / B3465DNF	Dell B2360 / B3460 / B3465 INTRO
Dell B2360D / B3460DN / B3465DNF	Dell B2360 / B3460 / B3465
Dell B2375DFW / B2375DNF	Dell B2375 Hi Cap
Dell B2375DFW / B2375DNF	Dell B2375 Std Cap
Dell B5460dn / B5465dnf	Dell B5460 / B5465 Hi Cap
Dell B5460dn / B5465dnf	Dell B5460 / B5465 INTRO
Dell B5460dn / B5465dnf	Dell B5460 / B5465 Std Cap
Dell C1660w	Dell C1660 Black Std Cap
Dell C1660w	Dell C1660 Cyan Std Cap
Dell C1660w	Dell C1660 Magenta Std Cap
Dell C1660w	Dell C1660 Yellow Std Cap
Dell C1660w	Dell C1660 Black Hi Cap
Dell C1660w	Dell C1660 Cyan Hi Cap
Dell C1660w	Dell C1660 Magenta Hi Cap
Dell C1660w	Dell C1660 Yellow Hi Cap
Dell C2660dn / C2665dnf	Dell C2660dn / C2665dnf Black
Dell C2660dn / C2665dnf	Dell C2660dn / C2665dnf Cyan
Dell C2660dn / C2665dnf	Dell C2660dn / C2665dnf Magenta
Dell C2660dn / C2665dnf	Dell C2660dn / C2665dnf Yellow
Dell C3760 / C3765	Dell C3760 / C3765 Black Hi Cap
Dell C3760 / C3765	Dell C3760 / C3765 Cyan Hi Cap
Dell C3760 / C3765	Dell C3760 / C3765 Magenta Hi Cap
Dell C3760 / C3765	Dell C3760 / C3765 Yellow Hi Cap
Dell C3760 / C3765	Dell C3760 / C3765 Black Std Cap
Dell C3760 / C3765	Dell C3760 / C3765 Cyan Std Cap
Dell C3760 / C3765	Dell C3760 / C3765 Magenta Std Cap
Dell C3760 / C3765	Dell C3760 / C3765 Yellow Std Cap
Dell E310dw/E514dw/E515dn/E515dw	Dell E310 E515 Hi Cap
Dell E310dw/E514dw/E515dn/E515dw	Dell E310 E515 Std Cap
Dell E525 Black	Dell E525 Black
Dell E525 Cyan	Dell E525 Cyan
Dell E525 Magenta	Dell E525 Magenta
Dell E525 Yellow	Dell E525 Yellow
Dell H625cdw/H825cdw/S2825cdn	Dell H625 Black
Dell H625cdw/H825cdw/S2825cdn	Dell H625 Cyan
Dell H625cdw/H825cdw/S2825cdn	Dell H625 Magenta
Dell H625cdw/H825cdw/S2825cdn	Dell H625 Yellow
Dell M5200	Dell M5200 ALL
Dell M5210	Dell M5210 / M5310 ALL (T640)
Dell P1700 / 1700N / 1710	Dell P1700 / P1710 ALL
Dell 1720 / 1720dn	Dell P1720 ALL
Dell S2500	Dell S2500 All
Dell W5300 / W5310	Dell W5300 All
Dell M5330	Dell W5330 All

Remanufactured / Refilled Dell Printers	Remanufactured / Refilled Dell Printers
Epson Printers	Epson Printers
Epson EPL-6200	Epson S050166 Hi Cap
Epson EPL-6200	Epson S050167 Std Cap
Epson Aculaser M2000D	Epson 0435 / 0436 / 0438
Epson Aculaser M2000D	Epson 0437 Hi Cap
Epson Aculaser M2000D	Epson 0435 / 0436 / 0437 / 0440 Intro
Epson C1600 / CX16 / CX16DNF / CX16NF	Epson S050554 Yellow Hi Cap
Epson C1600 / CX16 / CX16DNF / CX16NF	Epson S050555 Magenta Hi Cap
Epson C1600 / CX16 / CX16DNF / CX16NF	Epson S050556 Cyan Hi Cap
Epson C1600 / CX16 / CX16DNF / CX16NF	Epson S050557 Black Hi Cap
Epson C1600 / CX16 / CX16DNF / CX16NF	Epson S050558 Yellow Std Cap
Epson C1600 / CX16 / CX16DNF / CX16NF	Epson S050559 Magenta Std Cap
Epson C1600 / CX16 / CX16DNF / CX16NF	Epson S050560 Cyan Std Cap

Epson MX20 / M2400 / EPL-N2550	Epson 0582 / 0584 Hi Cap
Epson MX20 / M2300 / M2400	Epson 0583 / 0585 Std Cap
Epson AcuLaser M1200	Epson S050520 Black
Epson AcuLaser M1200	Epson S050521 Black
Epson AcuLaser M1200	Epson S050522 Black
Epson AcuLaser M1200	Epson S050523 Black Hi Cap
Epson C1700/c1750n/C1750w/CX17/CX17nf/CX17wf	Epson 0611 Yellow Hi Cap
Epson C1700/c1750n/C1750w/CX17/CX17nf/CX17wf	Epson 0612 Magenta Hi Cap
Epson C1700/c1750n/C1750w/CX17/CX17nf/CX17wf	Epson 0613 Cyan Hi Cap
Epson C1700/c1750n/C1750w/CX17/CX17nf/CX17wf	Epson 0614 Black Hi Cap
Epson AcuLaser M1400/MX14/MX14NF	Epson 0650 Hi Cap
Epson AcuLaser M1400/MX14/MX14NF	Epson 0651 Hi Cap
Epson AcuLaser M1400/MX14/MX14NF	Epson 0652 Std Cap
Epson C1700/c1750n/C1750w/CX17/CX17nf/CX17wf	Epson 0669 Yellow Std Cap
Epson C1700/c1750n/C1750w/CX17/CX17nf/CX17wf	Epson 0670 Magenta Std Cap
Epson C1700/c1750n/C1750w/CX17/CX17nf/CX17wf	Epson 0671 Cyan Std Cap
Epson C1700/c1750n/C1750w/CX17/CX17nf/CX17wf	Epson 0672 Black Std Cap
Epson AL-M300D Epson AL-M300DN	Epson 0689 / 0691 / AL-M300 Black Hi Cap
Epson AL-M300D Epson AL-M300DN	Epson 0690 AL-M300 Black Std Cap
Epson AL-M400DN	Epson 0698 / 0699 AL-M400 Black
Epson EPL-6200 Drum	Epson S051099 Drum
Epson C1100 / Dell 3000	Epson S051104 / Dell 3000 Drum
Epson EPL-N3000	Epson S051111
Epson C3800	Epson 1124 Yellow Hi Cap
Epson C3800	Epson 1125 Magenta Hi Cap
Epson C3800	Epson 1126 Cyan Hi Cap
Epson C3800	Epson 1127 Black Hi Cap
Epson C3800	Epson 1128 Yellow
Epson C3800	Epson 1129 Magenta
Epson C3800	Epson 1130 Cyan
Epson C2800 (Dell 3110 / Xerox 6180)	Epson 1158 Yellow Hi Cap
Epson C2800 (Dell 3110 / Xerox 6180)	Epson 1159 Magenta Hi Cap
Epson C2800 (Dell 3110 / Xerox 6180)	Epson 1160 Cyan Hi Cap
Epson C2800 (Dell 3110 / Xerox 6180)	Epson 1161 Black Hi Cap
Epson C2800 (Dell 3110 / Xerox 6180)	Epson 1162 Yellow Std Cap
Epson C2800 (Dell 3110 / Xerox 6180)	Epson 1163 Magenta Std Cap
Epson C2800 (Dell 3110 / Xerox 6180)	Epson 1164 Cyan Std Cap
Epson C2800 (Dell 3110 / Xerox 6180)	Epson 1165 Black Std Cap
Epson EPL-N4000	Epson S051060

Remanufactured / Refilled Epson Printers	Remanufactured / Refilled Epson Printers
HP LaserJet 4V/4MV	HP 00A / C3900A
HP 5P / 5MP / 6P / 6MP	HP 03A / C3903A
HP LaserJet P2035 / P2055 Black Toner	HP 05A / CE505A / Canon 719
HP LaserJet P2035 / P2055 Black Toner	HP 05X / CE505X / Canon 719H
HP 5L / 5ML / 6L / 6ML / 3100 / 3150	HP 06A / C3906A
HP Series 5Si / 8000	HP 09A/X / C3909A/X / Canon EP-W
HP Series 5Si / 8000	HP 09X / C3909X
HP LaserJet 2300 / 2300N	HP 10A / Q2610A
HP LaserJet 2410	HP 11A / Q6511A / Canon 710
HP LaserJet 2410	HP 11X / Q6511X / Canon 710H
HP LaserJet 1010/12/15/18/20/22/32/3015/20/30	HP 12A / Q2612A / Canon 703
HP 1300 / 1300A	HP 13A / Q2613A
HP 1300 / 1300X	HP 13X / Q2613X
HP LaserJet Enterprise 700 M712dn	HP 14A / CF214A
HP LaserJet Enterprise 700 M712dn	HP 14X / CF214X
HP LaserJet 1000 / 05 / 1200 / 20 / 3300 / 20 / 30 Std Cap	HP 15A / C7115A
HP LaserJet 1000 / 05 / 1200 / 20 / 3300 / 20 / 30 High Cap	HP 15X / C7115X
HP LaserJet Pro M102/MFP M130	HP 17A / CF217A
HP LaserJet Pro M102/MFP M130	HP 19A / CF219A Drum
HP LaserJet 5200 Printer series	HP 16A / Q7516A
HP 1150	HP 24A / Q2624A
HP LaserJet Enterprise Flow M830z / M806dn / M806x+	HP 25X / CF325X
HP LaserJet Pro M402 / MFP M426	HP 26A / CF226A Black
HP LaserJet Pro M402 / MFP M426	HP 26X / CF226X Hi Cap Black
HP 4000 / 4000N / 4000T / 4050	HP 27A / C4127A / Canon EP-53
HP 4000 / 4000N / 4000T / 4050	HP 27X / C4127X / Canon EP-52
HP 5000 / 5100	HP 29X / C4129X / Canon EP-62
HP LaserJet Pro M203/MFP M227	HP 30A / CF230A
HP LaserJet Pro M203/MFP M227	HP 30X / CF230X
HP LaserJet Pro M203/MFP M227	HP 30A / CF230A INTRO
HP LaserJet Pro M203/MFP M227	HP 32A / CF232A Drum
HP LaserJet P1005 / P1006 Printers	HP 35A / CB435A / Canon 712

HP LaserJet P1005 / P1006 Printers	HP 35A / CB435A / Canon 712 INTRO
HP LaserJet P1505 / P1505 Series	HP 36A / CB436A / Canon 713
HP LaserJet P1505 / P1505 Series	HP 36A / CB436A / Canon 713 INTRO
HP 4200	HP 38A / Q1338A
HP 4300	HP 39A / Q1339A
HP LaserJet 4240 / 4250 / 4350 Std Cap	HP 42A / Q5942A
HP LaserJet 4240 / 4250 / 4350 High Cap	HP 42X / Q5942X
HP 9000 Series	HP 43X / C8543X
HP 4345	HP 45A / Q5945A
HP LaserJet 1160 / 1320 / 1320n / 1320nw / 1320tn	HP 49A / Q5949A / Canon 708
HP LaserJet 1160 / 1320 / 1320n / 1320nw / 1320tn	HP 49X / Q5949X / Canon 708H
HP LaserJet M3027 / 3035 / P3005 Std Cap	HP 51A / Q7551A
HP LaserJet M3027 / 3035 / P3005 High Cap	HP 51X / Q7551X
HP LaserJet P2015 Printers Series A	HP 53A / Q7553A / Canon 715
HP LaserJet P2015 Printers Series X	HP 53X / Q7553X / Canon 715H
HP LaserJet Enterprise P3015	HP 55A / CE255A / Canon 724
HP LaserJet Enterprise P3015	HP 55X / CE255X / Canon 724H
HP 4100	HP 61A / C8061A
HP 4100	HP 61X / C8061X
HP LaserJet P4014 / P4015 / P4515 Series	HP 64A / CC364A
HP LaserJet P4015 / P4515 Series	HP 64X / CC364X
HP LaserJet M5025 mfp / 5035	HP 70A / Q7570A
HP LaserJet 4L / 4P / 4ML / 4MP	HP 74A / 92274A
HP IIIp / IIIPMAC / IIp / IIp Plus	HP 75A / 92275A
HP LaserJet Pro P1566	HP 78A / CE278A
HP LaserJet Pro P1566	HP 78A / CE278A INTRO
HP LaserJet Pro M12/MFP M26	HP 79A / CF279A
HP LaserJet Pro 400 M401 / MFP M425	HP 80A / CF280A / Canon 720
HP LaserJet Pro 400 M401 / MFP M425	HP 80X / CF280X / Canon 720H
HP LJ Enterprise Flow MFP M630 ALL	HP 81A / CF281A
HP LJ Enterprise Flow MFP M630 ALL	HP 81X / CF281X
HP 8100 & 8150 & Mopier 320	HP 82X / C4182X / Canon EP-72
HP LaserJet Pro MFP M125nw / M127fn	HP 83A / CF283A / Canon 737
HP LaserJet Pro MFP M125nw / M127fn	HP 83X / CF283X / Canon 737H
HP LaserJet Pro MFP M125nw / M127fn	HP 83A / CF283A / Canon 737 INTRO
HP LJ Pro M1132MFP/M1212NF/M1217nfw/P1100/p1102/P1104	HP 85A / CE285A / Canon 725
HP LJ Pro M1132MFP/M1212NF/M1217nfw/P1100/p1102/P1104	HP 85A / CE285A INTRO
HP LaserJet Enterprise M506dn / LaserJet Pro M501dn / M501n	HP 87A / CF287A
HP LaserJet Enterprise M506dn / LaserJet Pro M501dn / M501n	HP 87X / CF287X
HP LaserJet Pro 400 M425dw	HP 88A / CF288A
HP LaserJet Pro 400 M425dw	HP 88A / CF288A INTRO
HP LaserJet M4555f MFP	HP 90A CE390A
HP LaserJet M4555f MFP	HP 90X CE390X
HP 4si / 4si mx / IIIsi IIIsi mx	HP 91A / 92291A
HP 1100 / 1100A / 3200	HP 92A / C4092A
HP II / IID / III / IIID	HP 95A / 92295A
HP LaserJet 2100 series / 2200 series	HP 96A / C4096A
HP LaserJet 4 / 4+ / 4M / 4M+ / 5 / 5N / 5M	HP 98A / 92298A
HP LaserJet 4 / 4+ / 4M / 4M+ / 5 / 5N / 5M	HP 98X / 92298X
HP Color LaserJet 8500	HP C4149A Black
HP Color LaserJet 8500	HP C4150A Cyan
HP Color LaserJet 8500	HP C4151A Magenta
HP Color LaserJet 8500	HP C4152A Yellow
HP Color LaserJet 4500	HP C4191A Black
HP Color LaserJet 4500	HP C4192A Cyan
HP Color LaserJet 4500	HP C4193A Magenta
HP Color LaserJet 4500	HP C4194A Yellow
HP Color LaserJet 4500	HP C4195 Drum
HP Color LaserJet 9500	HP C8550 Black
HP Color LaserJet 9500	HP C8551 Cyan
HP Color LaserJet 9500	HP C8552 Yellow
HP Color LaserJet 9500	HP C8553 Magenta
HP Color LaserJet 9500	HP C8560A Black Drum
HP Color LaserJet 9500	HP C8561A Cyan Drum
HP Color LaserJet 9500	HP C8562A Yellow Drum
HP Color LaserJet 9500	HP C8563A Magenta Drum
HP 1500 / 2500 Black	HP C9700A / 121A / Canon 701 Black
HP 1500 / 2500 Color	HP C9701A / 121A / Canon 701 Cyan
HP 1500 / 2500 Color	HP C9702A / 121A / Canon 701 Yellow
HP 1500 / 2500 Color	HP C9703A / 121A / Canon 701 Magenta
HP 1500 / 2500 Drum	HP C9704A / 121A / Canon 701 Drum
HP Color LaserJet 4600 / 4650	HP C9720A / 641A Back

HP Color LaserJet 4600 / 4650	HP C9721A / 641A Cyan
HP Color LaserJet 4600 / 4650	HP C9722A / 641A Yellow
HP Color LaserJet 4600 / 4650	HP C9723A / 641A Magenta
HP Color LaserJet 5500 / 5550	HP C9730A / 645A Black
HP Color LaserJet 5500 / 5550	HP C9731A / 645A Cyan
HP Color LaserJet 5500 / 5550	HP C9732A / 645A Yellow
HP Color LaserJet 5500 / 5550	HP C9733A / 645A Magenta
HP Color LaserJet CP6015, CM6030, CM6040	HP CB380A / 823A Black
HP Color LaserJet CP6015, CM6030, CM6040	HP CB381A / 823A Cyan
HP Color LaserJet CP6015, CM6030, CM6040	HP CB382A / 823A Yellow
HP Color LaserJet CP6015, CM6030, CM6040	HP CB383A / 823A Magenta
HP Color LaserJet CP6015, CM6030, CM6040	HP CB384A / 824A Black Drum
HP Color LaserJet CP6015, CM6030, CM6040	HP CB385A / 824A Cyan Drum
HP Color LaserJet CP6015, CM6030, CM6040	HP CB386A / 824A Yellow Drum
HP Color LaserJet CP6015, CM6030, CM6040	HP CB387A / 824A Magenta Drum
HP Color LaserJet CM6030 / 6040	HP CB390A / 825A Black
HP Color LaserJet CP4005	HP CB400A / 642A Black
HP Color LaserJet CP4005	HP CB401A / 642A Cyan
HP Color LaserJet CP4005	HP CB402A / 642A Yellow
HP Color LaserJet CP4005	HP CB403A / 642A Magenta
HP Colour LJ CM1312/CP1215/CP1217/CP1510/CP1514/CP1515/CP1518	HP CB540A / 125A / Canon 716 Black
HP Colour LJ CM1312/CP1215/CP1217/CP1510/CP1514/CP1515/CP1518	HP CB541A / 125A / Canon 716 Cyan
HP Colour LJ CM1312/CP1215/CP1217/CP1510/CP1514/CP1515/CP1518	HP CB542A / 125A / Canon 716 Yellow
HP Colour LJ CM1312/CP1215/CP1217/CP1510/CP1514/CP1515/CP1518	HP CB543A / 125A / Canon 716 Magenta
HP Colour LJ CM1312/CP1215/CP1217/CP1510/CP1514/CP1515/CP1518	HP CB540A / 125A / Canon 716 Black INTRO
HP Colour LJ CM1312/CP1215/CP1217/CP1510/CP1514/CP1515/CP1518	HP CB541A / 125A / Canon 716 Cyan INTRO
HP Colour LJ CM1312/CP1215/CP1217/CP1510/CP1514/CP1515/CP1518	HP CB542A / 125A / Canon 716 Yellow INTRO
HP Colour LJ CM1312/CP1215/CP1217/CP1510/CP1514/CP1515/CP1518	HP CB543A / 125A / Canon 716 Magenta INTRO
HP Color LaserJet CP2025/CM2320	HP CC530A / 304A / Canon 718 Black
HP Color LaserJet CP2025/CM2320	HP CC531A / 304A / Canon 718 Cyan
HP Color LaserJet CP2025/CM2320	HP CC532A / 304A / Canon 718 Yellow
HP Color LaserJet CP2025/CM2320	HP CC533A / 304A / Canon 718 Magenta
HP Color LaserJet CP2025/CM2320	HP CC530A / 304A / Canon 718 Black INTRO
HP Color LaserJet CP2025/CM2320	HP CC531A / 304A / Canon 718 Cyan INTRO
HP Color LaserJet CP2025/CM2320	HP CC532A / 304A / Canon 718 Yellow INTRO
HP Color LaserJet CP2025/CM2320	HP CC533A / 304A / Canon 718 Magenta INTRO
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE250A / 504A / Canon 723 Black
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE250X / 504X / Canon 723H Black
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE251A / 504A / Canon 723 Cyan
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE252A / 504A / Canon 723 Yellow
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE253A / 504A / Canon 723 Magenta
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE250A / 504A / Canon 723 Black INTRO
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE251A / 504A / Canon 723 Cyan INTRO
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE252A / 504A / Canon 723 Yellow INTRO
HP CM 3530 FS MFP/MFP/CP 3525 DN/N/X	HP CE253A / 504A / Canon 723 Magenta INTRO
HP Colour LaserJet CP4525dn / CP4025n	HP CE260A Black Std Cap
HP Colour LaserJet CP4525dn / CP4025n	HP CE260X Black Hi Cap
HP Colour LaserJet CP4525dn / CP4025n	HP CE261A Cyan
HP Colour LaserJet CP4525dn / CP4025n	HP CE262A Yellow
HP Colour LaserJet CP4525dn / CP4025n	HP CE263A Magenta
HP Color LaserJet CM4540	HP CE264X Black Hi Cap
HP Colour LaserJet CP5520 / 5525dn / M750dn	HP CE270A / 650A Black
HP Colour LaserJet CP5520 / 5525dn / M750dn	HP CE271A / 650A Cyan
HP Colour LaserJet CP5520 / 5525dn / M750dn	HP CE272A / 650A Yellow
HP Colour LaserJet CP5520 / 5525dn / M750dn	HP CE273A / 650A Magenta
HP Color LaserJet CP1020 / CP1025	HP CE310A / 126A / Canon 729 Black
HP Color LaserJet CP1020 / CP1025	HP CE311A / 126A / Canon 729 Cyan
HP Color LaserJet CP1020 / CP1025	HP CE312A / 126A / Canon 729 Yellow
HP Color LaserJet CP1020 / CP1025	HP CE313A / 126A / Canon 729 Magenta
HP Color LaserJet CP1020 / CP1025	HP CE314A / 126A / Canon 029 Drum
HP Color LaserJet CP1020 / CP1025	HP CE310A / 126A / Canon 729 Black INTRO
HP Color LaserJet CP1020 / CP1025	HP CE311A / 126A / Canon 729 Cyan INTRO
HP Color LaserJet CP1020 / CP1025	HP CE312A / 126A / Canon 729 Yellow INTRO
HP Color LaserJet CP1020 / CP1025	HP CE313A / 126A / Canon 729 Magenta INTRO
HP Color LaserJet CP1415 / CP1525	HP CE320A / 128A Black
HP Color LaserJet CP1415 / CP1525	HP CE321A / 128A Cyan
HP Color LaserJet CP1415 / CP1525	HP CE322A / 128A Yellow
HP Color LaserJet CP1415 / CP1525	HP CE323A / 128A Magenta
HP Color LaserJet CP1415 / CP1525	HP CE320A / 128A Black INTRO
HP Color LaserJet CP1415 / CP1525	HP CE321A / 128A Cyan INTRO
HP Color LaserJet CP1415 / CP1525	HP CE322A / 128A Yellow INTRO
HP Color LaserJet CP1415 / CP1525	HP CE323A / 128A Magenta INTRO

HP LaserJet Enterprise 700 Color MFP M775dn	HP CE340A / 651A Black
HP LaserJet Enterprise 700 Color MFP M775dn	HP CE341A / 651A Cyan
HP LaserJet Enterprise 700 Color MFP M775dn	HP CE343A / 651A Magenta
HP LaserJet Enterprise 700 Color MFP M775dn	HP CE342A / 651A Yellow
HP LaserJet Enterprise 500 Colour M551dn/n/xh	HP CE400A / 507A / Canon 732 Black
HP LaserJet Enterprise 500 Colour M551dn/n/xh	HP CE400X / 507X / Canon 732H Black
HP LaserJet Enterprise 500 Colour M551dn/n/xh	HP CE401A / 507A / Canon 732 Cyan
HP LaserJet Enterprise 500 Colour M551dn/n/xh	HP CE402A / 507A / Canon 732 Yellow
HP LaserJet Enterprise 500 Colour M551dn/n/xh	HP CE403A / 507A / Canon 732 Magenta
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE410A / 305A Black
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE410X / 305X Black
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE411A / 305A Cyan
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE412A / 305A Yellow
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE413A / 305A Magenta
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE410A / 305A Black INTRO
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE411A / 305A Cyan INTRO
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE413A / 305A Magenta INTRO
HP LaserJet Pro 300 M351a/MFP M375nw/400 M451dn/MFP M475dn	HP CE412A / 305A Yellow INTRO
HP CP5225	HP CE740A / 307A Black
HP CP5225	HP CE741A / 307A Cyan
HP CP5225	HP CE742A / 307A Yellow
HP CP5225	HP CE743A / 307A Magenta
HP Color LaserJet CM4540	HP CF031A / 646A Cyan
HP Color LaserJet CM4540	HP CF032A / 646A Yellow
HP Color LaserJet CM4540	HP CF033A / 646A Magenta
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF210A / 131A / Canon 731 Black
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF210X / 131X / Canon 731H Black
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF211A / 131A / Canon 731 Cyan
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF212A / 131A / Canon 731 Yellow
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF213A / 131A / Canon 731 Magenta
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF210A / 131A / Canon 731 Black
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF211A / 131A / Canon 731 Cyan
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF212A / 131A / Canon 731 Yellow
HP LaserJet Pro 200 Color M251n / MFP M276n	HP CF213A / 131A / Canon 731 Magenta
HP Colour LaserJet Enterprise flow M880/+ NFC	HP CF300A / 827A Black
HP Colour LaserJet Enterprise flow M880/+ NFC	HP CF301A / 827A Cyan
HP Colour LaserJet Enterprise flow M880/+ NFC	HP CF302A / 827A Yellow
HP Colour LaserJet Enterprise flow M880/+ NFC	HP CF303A / 827A Magenta
HP Colour LaserJet Enterprise M855dn/x+/xh	HP CF310A / 826A Black
HP Colour LaserJet Enterprise M855dn/x+/xh	HP CF311A / 826A Cyan
HP Colour LaserJet Enterprise M855dn/x+/xh	HP CF312A / 826A Yellow
HP Colour LaserJet Enterprise M855dn/x+/xh	HP CF313A / 826A Magenta
HP Color LaserJet Ente M651dn/n/xh/Flow MFP M680z/dn/f	HP CF320A / 652A Black
HP Color LaserJet Enterprise Flow MFP M680z/dn/f	HP CF320X / 653X Black
HP Color LaserJet Enterprise Flow MFP M680z/dn/f	HP CF321A / 653A Cyan
HP Color LaserJet Enterprise Flow MFP M680z/dn/f	HP CF322A / 653A Yellow
HP Color LaserJet Enterprise Flow MFP M680z/dn/f	HP CF323A / 653A Magenta
HP Colour LaserJet Enterprise M651	HP CF330A / 654A Black
HP Colour LaserJet Enterprise M651	HP CF330X / 654X Black
HP Colour LaserJet Enterprise M651	HP CF331A / 654A Cyan
HP Colour LaserJet Enterprise M651	HP CF332A / 654A Yellow
HP Colour LaserJet Enterprise M651	HP CF333A / 654A Magenta
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF350A / 130A Black
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF351A / 130A Cyan
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF352A / 130A Yellow
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF353A / 130A Magenta
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF350A / 130A Black INTRO
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF351A / 130A Cyan INTRO
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF352A / 130A Yellow INTRO
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF353A / 130A Magenta INTRO
HP Colour LaserJet Enterprise flow M880/M855	HP CF358A / 828A Drum Black
HP Colour LaserJet Enterprise flow M880/M855	HP CF359A / 828A Drum Cyan
HP Colour LaserJet Enterprise flow M880/M855	HP CF364A / 828A Drum Yellow
HP Colour LaserJet Enterprise flow M880/M855	HP CF365A / 828A Drum Magenta
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF360A / 508A Black
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF361A / 508A Cyan
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF362A / 508A Yellow
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF363A / 508A Magenta
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF360X / 508X Black Hi-Cap
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF361X / 508X Cyan Hi-Cap
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF362X / 508X Yellow Hi-Cap
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF363X / 508X Magenta Hi-Cap

HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF380X / 312X Black
HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF380A / 312A Black
HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF381A / 312A Cyan
HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF382A / 312A Yellow
HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF383A / 312A Magenta
HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF380A / 312A Black INTRO
HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF381A / 312A Cyan INTRO
HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF382A / 312A Yellow INTRO
HP Colour LaserJet Pro MFP M476dn/dw/nw	HP CF383A / 312A Magenta INTRO
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF400X / 201X Black Hi-Cap
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF401X / 201X Cyan Hi-Cap
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF402X / 201X Yellow Hi-Cap
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF403X / 201X Magenta Hi-Cap
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF400A / 201A Black
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF401A / 201A Cyan
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF402A / 201A Yellow
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF403A / 201A Magenta
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF400A / 201A Black INTRO
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF401A / 201A Cyan INTRO
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF402A / 201A Yellow INTRO
HP Colour LaserJet Pro M252dw/M252n/MFP M277dw/M277n	HP CF403A / 201A Magenta INTRO
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF410X / 410X Black Hi Cap
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF411X / 410X Cyan Hi Cap
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF412X / 410X Yellow Hi Cap
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF413X / 410X Magenta Hi Cap
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF410A / 410A Black
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF411A / 410A Cyan
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF412A / 410A Yellow
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF413A / 410A Magenta
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF410A / 410A Black INTRO
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF411A / 410A Cyan INTRO
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF412A / 410A Yellow INTRO
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF413A / 410A Magenta INTRO
HP Color LaserJet 3500 / 3550 / 3700	HP Q2670A / 308A Black
HP Color LaserJet 3500 / 3550 / 3700	HP Q2671A / 308A Cyan
HP Color LaserJet 3500 / 3550 / 3700	HP Q2672A / 308A Yellow
HP Color LaserJet 3500 / 3550 / 3700	HP Q2673A / 308A Magenta
HP Color Laserjet 3700	HP Q2681A / 308A Cyan
HP Color Laserjet 3700	HP Q2682A / 308A Yellow
HP Color Laserjet 3700	HP Q2683A / 308A Magenta
HP Colour Laserjet 2550 / 2820 / 2840 / 2800	HP Q3960A / 122 Black
HP Colour Laserjet 2550 / 2820 / 2840 / 2800	HP Q3961A / 122 Cyan
HP Colour Laserjet 2550 / 2820 / 2840 / 2800	HP Q3962A / 122 Yellow
HP Colour Laserjet 2550 / 2820 / 2840 / 2800	HP Q3963A / 122 Magenta
HP Colour Laserjet 2550 / 2820 / 2840 / 2800	HP Q3964A / 122 Drum
HP Colour Laserjet 2550 / 2820 / 2840 / 2800	HP Q3971A / 122 Cyan
HP Colour Laserjet 2550 / 2820 / 2840 / 2800	HP Q3972A / 122 Yellow
HP Colour Laserjet 2550 / 2820 / 2840 / 2800	HP Q3973A / 122 Magenta
HP 4700 (Black)	HP Q5950A / 643A Black
HP 4700 (Color)	HP Q5951A / 643A Cyan
HP 4700 (Color)	HP Q5952A / 643A Yellow
HP 4700 (Color)	HP Q5953A / 643A Magenta
HP Color LaserJet 2600 / 2605 / 1015 / 1017	HP Q6000A / 124A / Canon 707 Black
HP Color LaserJet 2600 / 2605 / 1015 / 1017	HP Q6001A / 124A / Canon 707 Cyan
HP Color LaserJet 2600 / 2605 / 1015 / 1017	HP Q6002A / 124A / Canon 707 Yellow
HP Color LaserJet 2600 / 2605 / 1015 / 1017	HP Q6003A / 124A / Canon 707 Magenta
HP Color LaserJet 2600 / 2605 / 1015 / 1017	HP Q6000A / 124A / Canon 707 Black INTRO
HP Color LaserJet 2600 / 2605 / 1015 / 1017	HP Q6001A / 124A / Canon 707 Cyan INTRO
HP Color LaserJet 2600 / 2605 / 1015 / 1017	HP Q6002A / 124A / Canon 707 Yellow INTRO
HP Color LaserJet 2600 / 2605 / 1015 / 1017	HP Q6003A / 124A / Canon 707 Magenta INTRO
HP 4730	HP Q6460A / 644A Black
HP 4730	HP Q6461A / 644A Cyan
HP 4730	HP Q6462A / 644A Yellow
HP 4730	HP Q6463A / 644A Magenta
HP Color LaserJet 3600 / 3800 / CP3505	HP Q6470A / 501A / Canon 711 Black
HP Color LaserJet 3600 / 3800 / CP3505	HP Q6471A / 501A / Canon 711 Cyan
HP Color LaserJet 3600 / 3800 / CP3505	HP Q6472A / 501A / Canon 711 Yellow
HP Color LaserJet 3600 / 3800 / CP3505	HP Q6473A / 501A / Canon 711 Magenta
HP 2700 / 3000 (black)	HP Q7560A / 314A Black
HP 2700 / 3000 (Color)	HP Q7561A / 314A Cyan
HP 2700 / 3000 (Color)	HP Q7562A / 314A Yellow
HP 2700 / 3000 (Color)	HP Q7563A / 314A Magenta

Remanufactured / Refilled HP Laser Printers	Remanufactured / Refilled HP Laser Printers
HP Colour LaserJet 3800 / CP3505	HP Q7581A / 503A Cyan
HP Colour LaserJet 3800 / CP3505	HP Q7582A / 503A Yellow
HP Colour LaserJet 3800 / CP3505	HP Q7583A / 503A Magenta
HP LaserJet P2035 / P2055 Black Toner	HP 05A / CE505A / Canon 719 (REMAN)
HP LaserJet P2035 / P2055 Black Toner	HP 05X / CE505X / Canon 719H (REMAN)
HP LaserJet Pro M402 / MFP M426	HP 26A / CF226A Black (REMAN)
HP LaserJet Pro M402 / MFP M426	HP 26X / CF226X Hi Cap Black (REMAN)
HP 4200	HP 38A / Q1338A (REMAN)
HP 4300	HP 39A / Q1339A (REMAN)
HP LaserJet 4240 / 4250 / 4350 Std Cap	HP 42A / Q5942A (REMAN)
HP LaserJet 4240 / 4250 / 4350 High Cap	HP 42X / Q5942X (REMAN)
HP 4345	HP 45A / Q5945A (REMAN)
HP LaserJet Enterprise P3015	HP 55A / CE255A / Canon 724 (REMAN)
HP LaserJet Enterprise P3015	HP 55X / CE255X / Canon 724H (REMAN)
HP LaserJet P4014 / P4015 / P4515 Series	HP 64A / CC364A (REMAN)
HP LaserJet P4015 / P4515 Series	HP 64X / CC364X (REMAN)
HP LaserJet Pro 400 M401 / MFP M425	HP 80A / CF280A (REMAN)
HP LaserJet Pro 400 M401 / MFP M425	HP 80X / CF280X (REMAN)
HP LJ Enterprise Flow MFP M630 ALL	HP 81A / CF281A (REMAN)
HP LJ Enterprise Flow MFP M630 ALL	HP 81X / CF281X (REMAN)
HP LaserJet Pro MFP M125nw / M127fn	HP 83X / CF283X (REMAN)
HP LaserJet Enterprise M506dn / LaserJet Pro M501dn / M501n	HP 87A / CF287A (REMAN)
HP LaserJet Enterprise M506dn / LaserJet Pro M501dn / M501n	HP 87A / CF287A INTRO (REMAN)
HP LaserJet Enterprise M506dn / LaserJet Pro M501dn / M501n	HP 87X / CF287X
HP LaserJet M4555f MFP	HP 90A CE390A (REMAN)
HP LaserJet M4555f MFP	HP 90X CE390X (REMAN)
HP Color LaserJet 5500 / 5550	HP C9730A / 645A Black (REMAN)
HP Color LaserJet 5500 / 5550	HP C9731A / 645A Cyan (REMAN)
HP Color LaserJet 5500 / 5550	HP C9732A / 645A Yellow (REMAN)
HP Color LaserJet 5500 / 5550	HP C9733A / 645A Magenta (REMAN)
HP Color LaserJet CP4005	HP CB401A / 642A Cyan (REMAN)
HP Color LaserJet CP4005	HP CB402A / 642A Yellow (REMAN)
HP Color LaserJet CP4005	HP CB403A / 642A Magenta (REMAN)
HP Colour LaserJet CP5520 / 5525dn / M750dn	HP CE270A / 650A Black (REMAN)
HP Colour LaserJet CP5520 / 5525dn / M750dn	HP CE271A / 650A Cyan (REMAN)
HP Colour LaserJet CP5520 / 5525dn / M750dn	HP CE272A / 650A Yellow (REMAN)
HP Colour LaserJet CP5520 / 5525dn / M750dn	HP CE273A / 650A Magenta (REMAN)
HP Color LaserJet CP1020 / CP1025	HP CE310A / 126A Black / Canon 729 (REMAN)
HP Color LaserJet CP1020 / CP1025	HP CE311A / 126A Cyan / Canon 729 (REMAN)
HP Color LaserJet CP1020 / CP1025	HP CE312A / 126A Yellow / Canon 729 (REMAN)
HP Color LaserJet CP1020 / CP1025	HP CE313A / 126A Magenta / Canon 729 (REMAN)
HP Color LaserJet CP1020 / CP1025	HP CE310A / 126A Black INTRO (REMAN)
HP Color LaserJet CP1020 / CP1025	HP CE311A / 126A Cyan INTRO (REMAN)
HP Color LaserJet CP1020 / CP1025	HP CE312A / 126A Yellow INTRO (REMAN)
HP Color LaserJet CP1020 / CP1025	HP CE313A / 126A Magenta INTRO (REMAN)
HP CP5225	HP CE740A / 307A Black (REMAN)
HP CP5225	HP CE741A / 307A Cyan (REMAN)
HP CP5225	HP CE742A / 307A Yellow (REMAN)
HP CP5225	HP CE743A / 307A Magenta (REMAN)
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF350A / 130A Black (REMAN)
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF351A / 130A Cyan (REMAN)
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF352A / 130A Yellow (REMAN)
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF353A / 130A Magenta (REMAN)
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF350A / 130A Black INTRO (REMAN)
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF351A / 130A Cyan INTRO (REMAN)
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF352A / 130A Yellow INTRO (REMAN)
HP Colour LaserJet Pro MFP M176n / M177fw	HP CF353A / 130A Magenta INTRO (REMAN)
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF360X / 508X Black Hi-Cap (REMAN)
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF361X / 508X Cyan Hi-Cap (REMAN)
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF362X / 508X Yellow Hi-Cap (REMAN)
HP Colour LaserJet Enterprise M552dn/M553dn/M553x	HP CF363X / 508X Magenta Hi-Cap (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF410X / 410X Black Hi Cap (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF411X / 410X Cyan Hi Cap (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF412X / 410X Yellow Hi Cap (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF413X / 410X Magenta Hi Cap (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF410A / 410A Black (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF411A / 410A Cyan (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF412A / 410A Yellow (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF413A / 410A Magenta (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF410A / 410A Black INTRO (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF411A / 410A Cyan INTRO (REMAN)

HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF412A / 410A Yellow INTRO (REMAN)
HP Colour LaserJet MFP M477 / Pro M452 / Pro MFP M477	HP CF413A / 410A Magenta INRTO (REMAN)
HP 4700 (Color)	HP Q5951A / 643A Cyan (REMAN)
HP 4700 (Color)	HP Q5952A / 643A Yellow (REMAN)
HP 4700 (Color)	HP Q5953A / 643A Magenta (REMAN)
HP 4730	HP Q6460A / 644A Black (REMAN)
HP 4730	HP Q6461A / 644A Cyan (REMAN)
HP 4730	HP Q6462A / 644A Yellow (REMAN)
HP 4730	HP Q6463A / 644A Magenta (REMAN)
IBM Laser Printers	IBM Laser Printers
IBM Infoprint 1832 / 1852 / 1872 (T650)	IBM 39V2513 / 2515 Black
IBM Infoprint 1832 / 1852 / 1872 (T650)	IBM 39V2511 Black
QMS / Konica Minolta Laser Printers	QMS / Konica Minolta Laser Printers
QMS MagiColor 1600W / 1650EN / 1680MF / 1690MF	Konica A0V301H Black
QMS MagiColor 1600W / 1650EN / 1680MF / 1690MF	Konica A0V30HH Cyan
QMS MagiColor 1600W / 1650EN / 1680MF / 1690MF	Konica A0V30CH Magenta
QMS MagiColor 1600W / 1650EN / 1680MF / 1690MF	Konica A0V306H Yellow
QMS MagiColor 1600W / 1650EN / 1680MF / 1690MF	Konica A0V30GH Cyan Std Cap
QMS MagiColor 1600W / 1650EN / 1680MF / 1690MF	Konica A0V30AH Magenta Std Cap
QMS MagiColor 1600W / 1650EN / 1680MF / 1690MF	Konica A0V305H Yellow Std Cap
Konica Minolta MagiColor 5430 / 5430DL	Konica 1710582-001 Black Hi Cap
Konica Minolta MagiColor 5430 / 5430DL	Konica 1710582-002 Yellow Hi Cap
Konica Minolta MagiColor 5430 / 5430DL	Konica 1710582-003 Magenta Hi Cap
Konica Minolta MagiColor 5430 / 5430DL	Konica 1710582-004 Cyan Hi Cap
Konica Minolta MagiColor 5440 / 5450	Konica 1710604-005 / 001 Black
Konica Minolta MagiColor 5440 / 5450	Konica 1710604-004 / 008 Cyan
Konica Minolta MagiColor 5440 / 5450	Konica 1710604-003 / 007 Magenta
Konica Minolta MagiColor 5440 / 5450	Konica 1710604-002 / 006 Yellow
Konica Minolta Magicolor 5500/5550/5570/5650EN	Konica A06V Black
Konica Minolta Magicolor 5500/5550/5570/5650EN	Konica A06V Cyan
Konica Minolta Magicolor 5500/5550/5570/5650EN	Konica A06V Magenta
Konica Minolta Magicolor 5500/5550/5570/5650EN	Konica A06V Yellow
Konica Minolta C220 Black	Konica TN-216 Black
Konica Minolta C220 Cyan	Konica TN-216 Cyan
Konica Minolta C220 Magenta	Konica TN-216 Magenta
Konica Minolta C220 Yellow	Konica TN-216 Yellow
Konica Minolta TN-310 Black	Konica TN-310 Black
Konica Minolta TN-310 Cyan	Konica TN-310 Cyan
Konica Minolta TN-310 Magenta	Konica TN-310 Magenta
Konica Minolta TN-310 Yellow	Konica TN-310 Yellow
Konica Minolta Bizhub C360	Konica TN-319 Black
Konica Minolta Bizhub C360	Konica TN-319 Cyan
Konica Minolta Bizhub C360	Konica TN-319 Magenta
Konica Minolta Bizhub C360	Konica TN-319 Yellow
Konica Minolta C224 Black	Konica TN-321 Black
Konica Minolta C224 Cyan	Konica TN-321 Cyan
Konica Minolta C224 Magenta	Konica TN-321 Magenta
Konica Minolta C224 Yellow	Konica TN-321 Yellow
Konica Minolta Bizhub C258/C308/C368	Konica TN-324 Black
Konica Minolta Bizhub C258/C308/C368	Konica TN-324 Cyan
Konica Minolta Bizhub C258/C308/C368	Konica TN-324 Magenta
Konica Minolta Bizhub C258/C308/C368	Konica TN-324 Yellow
Konica Minolta C454 Black	Konica TN-512 Black
Konica Minolta C454 Cyan	Konica TN-512 Cyan
Konica Minolta C454 Magenta	Konica TN-512 Magenta
Konica Minolta C454 Yellow	Konica TN-512 Yellow
Konica Minolta Bizhub C451/C550/C650	Konica TN-611 Black
Konica Minolta Bizhub C451/C550/C650	Konica TN-611 Cyan
Konica Minolta Bizhub C451/C550/C650	Konica TN-611 Magenta
Konica Minolta Bizhub C451/C550/C650	Konica TN-611 Yellow
Konica Minolta Bizhub C452/C552/C652/C652DS	Konica TN-613 Black
Konica Minolta Bizhub C452/C552/C652/C652DS	Konica TN-613 Cyan
Konica Minolta Bizhub C452/C552/C652/C652DS	Konica TN-613 Magenta
Konica Minolta Bizhub C452/C552/C652/C652DS	Konica TN-613 Yellow
Konica Minolta Bizhub C654/C754	Konica TN-711 Black
Konica Minolta Bizhub C654/C754	Konica TN-711 Cyan
Konica Minolta Bizhub C654/C754	Konica TN-711 Magenta
Konica Minolta Bizhub C654/C754	Konica TN-711 Yellow
Konica Minolta Bizhub 3320 A6WT00H	Konica TNP-41 Black
Konica Minolta Bizhub 4050/4750 A6VK01H	Konica TNP-44 Black
Konica Minolta Bizhub 4050/4750 A6VK01W	Konica TNP-46 Black
QMS MagiColor 4650DN / 4690MF / 4695MF / 5670EN	QMS A0DK151 Black

QMS MagiColor 4650DN / 4690MF / 4695MF / 5670EN	QMS A0DK251 Yellow
QMS MagiColor 4650DN / 4690MF / 4695MF / 5670EN	QMS A0DK351 Magenta
QMS MagiColor 4650DN / 4690MF / 4695MF / 5670EN	QMS A0DK451 Cyan
Remanufactured / Refilled QMS / Konica Minolta Laser Printers	Remanufactured / Refilled QMS / Konica Minolta Laser Printers
Kyocera Fax & Laser Printers	Kyocera Fax & Laser Printers
Kyocera KM-1500	Kyocera TK-100
Kyocera TK-110	Kyocera TK-110
Kyocera FS-1041 / FS-1220MFP / FS-1320MFP	Kyocera TK-1115 Black
Kyocera FS-1061DN / FS-1325MFP	Kyocera TK-1125 Black
Kyocera FS-1030MFP / 1130MFP	Kyocera TK-1130 Black
Kyocera TK-1140	Kyocera TK-1140
Kyocera TK 1150 virgin	Kyocera TK 1150
Kyocera TK 1160 virgin	Kyocera TK 1160
Kyocera TK 1170 virgin	Kyocera TK 1170
Kyocera TK-120 Black	Kyocera TK-120 Black
Kyocera TK-130 Black	Kyocera TK-130 Black
Kyocera FS-1100	Kyocera TK-140 Black
Kyocera TK150 Black	Kyocera TK-150 Black
Kyocera TK150 Cyan	Kyocera TK-150 Cyan
Kyocera TK150 Magenta	Kyocera TK-150 Magenta
Kyocera TK150 Yellow	Kyocera TK-150 Yellow
Kyocera TK150 Black	Kyocera TK-150 Black INTRO
Kyocera TK150 Cyan	Kyocera TK-150 Cyan INTRO
Kyocera TK150 Magenta	Kyocera TK-150 Magenta INTRO
Kyocera TK150 Yellow	Kyocera TK-150 Yellow INTRO
Kyocera TK-160 Black	Kyocera TK-160 Black
Kyocera TK-170 / 172 Black	Kyocera TK-170 / 172 Black
Kyocera TK-310 Black	Kyocera TK-310 Black
Kyocera TK-3100 Black	Kyocera TK-3100 Black
Kyocera FS-4100DN	Kyocera TK-3110 Black
Kyocera FS-4200DN / FS-4300DN	Kyocera TK-3130 Black
Kyocera TK-3150 Black	Kyocera TK-3150 Black
Kyocera TK 3160	Kyocera TK 3160
Kyocera TK 3170	Kyocera TK 3170
Kyocera TK 3190	Kyocera TK 3190
Kyocera TK-320	Kyocera TK-320
Kyocera TK-330	Kyocera TK-330
Kyocera TK-340 Black	Kyocera TK-340 Black
Kyocera TK-350 Black	Kyocera TK-350 Black
Kyocera TK-360	Kyocera TK-360
Kyocera TASKalfa 1800/1801/2200/2201	Kyocera TK-4105 Black
Kyocera FS-6970DN	Kyocera TK-450
Kyocera TASKalfa 265ci / 266ci	Kyocera TK-5135 Black
Kyocera TASKalfa 265ci / 266ci	Kyocera TK-5135 Black Hi Cap
Kyocera TASKalfa 265ci / 266ci	Kyocera TK-5135 Cyan
Kyocera TASKalfa 265ci / 266ci	Kyocera TK-5135 Magenta
Kyocera TASKalfa 265ci / 266ci	Kyocera TK-5135 Yellow
Kyocera ECOSYS M6030cdn / M6530cdn / P6130cdn	Kyocera TK-5140 Black
Kyocera ECOSYS M6030cdn / M6530cdn / P6130cdn	Kyocera TK-5140 Cyan
Kyocera ECOSYS M6030cdn / M6530cdn / P6130cdn	Kyocera TK-5140 Magenta
Kyocera ECOSYS M6030cdn / M6530cdn / P6130cdn	Kyocera TK-5140 Yellow
Kyocera ECOSYS M6035cidn/M6535cidn/P6035cdn	Kyocera TK-5150 Black
Kyocera ECOSYS M6035cidn/M6535cidn/P6035cdn	Kyocera TK-5150 Cyan
Kyocera ECOSYS M6035cidn/M6535cidn/P6035cdn	Kyocera TK-5150 Magenta
Kyocera ECOSYS M6035cidn/M6535cidn/P6035cdn	Kyocera TK-5150 Yellow
Kyocera TK 5160 Black	Kyocera TK 5160 Black
Kyocera TK 5160 Cyan	Kyocera TK 5160 Cyan
Kyocera TK 5160 Magenta	Kyocera TK 5160 Magenta
Kyocera TK 5160 Yellow	Kyocera TK 5160 Yellow
Kyocera TK-5205 Cyan	Kyocera TK-5205 Cyan
Kyocera TK-5205 Magenta	Kyocera TK-5205 Magenta
Kyocera TK-5205 Yellow	Kyocera TK-5205 Yellow
Kyocera TK-5220 Black	Kyocera TK-5220 Black
Kyocera TK-5220 Cyan	Kyocera TK-5220 Cyan
Kyocera TK-5220 Magenta	Kyocera TK-5220 Magenta
Kyocera TK-5220 Yellow	Kyocera TK-5220 Yellow
Kyocera TK-5240 Black	Kyocera TK-5240 Black
Kyocera TK-5240 Cyan	Kyocera TK-5240 Cyan
Kyocera TK-5240 Magenta	Kyocera TK-5240 Magenta
Kyocera TK-5240 Yellow	Kyocera TK-5240 Yellow
Kyocera TK-540 Black	Kyocera TK-5405 Black
Kyocera TK-540 Cyan	Kyocera TK-540 Cyan

Kyocera TK-540 Magenta	Kyocera TK-540 Magenta
Kyocera TK-540 Yellow	Kyocera TK-540 Yellow
Kyocera TK-560 Black	Kyocera TK-560 Black
Kyocera TK-560 Cyan	Kyocera TK-560 Cyan
Kyocera TK-560 Magenta	Kyocera TK-560 Magenta
Kyocera TK-560 Yellow	Kyocera TK-560 Yellow
Kyocera TK-570 Black	Kyocera TK-570 Black
Kyocera TK-570 Cyan	Kyocera TK-570 Cyan
Kyocera TK-570 Magenta	Kyocera TK-570 Magenta
Kyocera TK-570 Yellow	Kyocera TK-570 Yellow
Kyocera TK-580 Black	Kyocera TK-580 Black
Kyocera TK-580 Cyan	Kyocera TK-580 Cyan
Kyocera TK-580 Magenta	Kyocera TK-580 Magenta
Kyocera TK-580 Yellow	Kyocera TK-580 Yellow
Kyocera TK-590 Black	Kyocera TK-590 Black
Kyocera TK-590 Cyan	Kyocera TK-590 Cyan
Kyocera TK-590 Magenta	Kyocera TK-590 Magenta
Kyocera TK-590 Yellow	Kyocera TK-590 Yellow
Kyocera TK-675 Black	Kyocera TK-675 Black
Kyocera TK-895 Black	Kyocera TK-895 Black
Kyocera TK-895 Cyan	Kyocera TK-895 Cyan
Kyocera TK-895 Magenta	Kyocera TK-895 Magenta
Kyocera TK-895 Yellow	Kyocera TK-895 Yellow
Kyocera TASKalfa 3050ci / 3550ci	Kyocera TK-8305 Black
Kyocera TASKalfa 3050ci / 3550ci	Kyocera TK-8305 Cyan
Kyocera TASKalfa 3050ci / 3550ci	Kyocera TK-8305 Magenta
Kyocera TASKalfa 3050ci / 3550ci	Kyocera TK-8305 Yellow
Kyocera TASKalfa 2550ci	Kyocera TK-8315 Black
Kyocera TASKalfa 2550ci	Kyocera TK-8315 Cyan
Kyocera TASKalfa 2550ci	Kyocera TK-8315 Magenta
Kyocera TASKalfa 2550ci	Kyocera TK-8315 Yellow
Kyocera TASKalfa 2551ci	Kyocera TK-8325 Black
Kyocera TASKalfa 2551ci	Kyocera TK-8325 Cyan
Kyocera TASKalfa 2551ci	Kyocera TK-8325 Magenta
Kyocera TASKalfa 2551ci	Kyocera TK-8325 Yellow
Kyocera TK-8335 Black	Kyocera TK-8335 Black
Kyocera TK-8335 Cyan	Kyocera TK-8335 Cyan
Kyocera TK-8335 Magenta	Kyocera TK-8335 Magenta
Kyocera TK-8335 Yellow	Kyocera TK-8335 Yellow
Kyocera TK-8345 Black	Kyocera TK-8345 Black
Kyocera TK-8345 Cyan	Kyocera TK-8345 Cyan
Kyocera TK-8345 Magenta	Kyocera TK-8345 Magenta
Kyocera TK-8345 Yellow	Kyocera TK-8345 Yellow
Kyocera TASKalfa 4550ci / 5550ci	Kyocera TK-8505 Black
Kyocera TASKalfa 4550ci / 5550ci	Kyocera TK-8505 Cyan
Kyocera TASKalfa 4550ci / 5550ci	Kyocera TK-8505 Magenta
Kyocera TASKalfa 4550ci / 5550ci	Kyocera TK-8505 Yellow
Kyocera TASKalfa 5052ci / 6052ci	Kyocera TK-8515 Black
Kyocera TASKalfa 5052ci / 6052ci	Kyocera TK-8515 Cyan
Kyocera TASKalfa 5052ci / 6052ci	Kyocera TK-8515 Magenta
Kyocera TASKalfa 5052ci / 6052ci	Kyocera TK-8515 Yellow
Kyocera TK-8525 Black	Kyocera TK-8525 Black
Kyocera TK-8525 Cyan	Kyocera TK-8525 Cyan
Kyocera TK-8525 Magenta	Kyocera TK-8525 Magenta
Kyocera TK-8525 Yellow	Kyocera TK-8525 Yellow
Kyocera FS-C8600DN / C8650DN	Kyocera TK-8600 Black
Kyocera FS-C8600DN / C8650DN	Kyocera TK-8600 Cyan
Kyocera FS-C8600DN / C8650DN	Kyocera TK-8600 Magenta
Kyocera FS-C8600DN / C8650DN	Kyocera TK-8600 Yellow
Kyocera TK-865 Black	Kyocera TK-865 Black
Remanufactured / Refilled Kyocera Fax & Laser Printers	Remanufactured / Refilled Kyocera Fax & Laser Printers
Kyocera TK-130 Black	Kyocera TK-130 Black (REMAN)
Kyocera TK-160 Black	Kyocera TK-160 Black (REMAN)
Kyocera TK-170 / 172 Black	Kyocera TK-170 / 172 Black (REMAN)
Kyocera TK-560 Black	Kyocera TK-560 Black (REMAN)
Kyocera TK-560 Cyan	Kyocera TK-560 Cyan (REMAN)
Kyocera TK-560 Magenta	Kyocera TK-560 Magenta (REMAN)
Kyocera TK-560 Yellow	Kyocera TK-560 Yellow (REMAN)
Kyocera TK-675 Black	Kyocera TK-675 Black (REMAN)
Lexmark Fax & Laser Printers	Lexmark Fax & Laser Printers
Lexmark 4039	Lexmark 1380850
Lexmark 4039	Lexmark 1380950 Hi Cap

Lexmark 4049	Lexmark 1382100
Lexmark 4049	Lexmark 1382150 Hi Cap
Lexmark C752	Lexmark 15G032K HC B
Lexmark C752	Lexmark 15G032C HC C
Lexmark C752	Lexmark 15G032M HC M
Lexmark C752	Lexmark 15G032Y HC Y
Lexmark C752	Lexmark C752 Series ALL Black
Lexmark C752	Lexmark C752 Series ALL Cyan
Lexmark C752	Lexmark C752 Series ALL Magenta
Lexmark C752	Lexmark C752 Series ALL Yellow
Lexmark C752	Lexmark 15G042K HI CAP B
Lexmark C752	Lexmark 15G042C HI CAP C
Lexmark C752	Lexmark 15G042M HI CAP M
Lexmark C752	Lexmark 15G042Y HI CAP Y
Lexmark C1200	Lexmark 12A1451
Lexmark C1200	Lexmark 12A1452
Lexmark C1200	Lexmark 12A1453
Lexmark C1200	Lexmark 12A1454
Lexmark C500 / X500N / X502N	Lexmark C500 Series ALL Black
Lexmark C500 / X500N / X502N	Lexmark C500 Series ALL Cyan
Lexmark C500 / X500N / X502N	Lexmark C500 Series ALL Magenta
Lexmark C500 / X500N / X502N	Lexmark C500 Series ALL Yellow
Lexmark C500 / X500N / X502N	Lexmark C500S2KG Black Std Cap
Lexmark C500 / X500N / X502N	Lexmark C500S2MG Magenta Std Cap
Lexmark C500 / X500N / X502N	Lexmark C500S2YG Yellow Std Cap
Lexmark C500 / X500N / X502N	Lexmark C500S2CG Cyan Std Cap
Lexmark C510 / C510N	Lexmark 20K0500 Cyan
Lexmark C510 / C510N	Lexmark 20K0501 Magenta
Lexmark C510 / C510N	Lexmark 20K0502 Yellow
Lexmark C510 / C510N	Lexmark 20K0503 Black
Lexmark C510 / C510N	Lexmark 20K0504 Drum
Lexmark C510 / C510N	Lexmark 20K1400 Cyan Hi Cap
Lexmark C510 / C510N	Lexmark 20K1401 Magenta Hi Cap
Lexmark C510 / C510N	Lexmark 20K1402 Yellow Hi Cap
Lexmark C510 / C510N	Lexmark 20K1403 Black Hi Cap
Lexmark C520 / C530	Lexmark C5200KS Black
Lexmark C520 / C530	Lexmark C5200CS Cyan
Lexmark C520 / C530	Lexmark C5200MS Magenta
Lexmark C520 / C530	Lexmark C5200YS Yellow
Lexmark C522 / C524	Lexmark C5220CS / C5222CS Cyan
Lexmark C522 / C524	Lexmark C5220KS / C5222KS Black
Lexmark C522 / C524	Lexmark C5220MS / C5222MS Magenta
Lexmark C522 / C524	Lexmark C5220YS / C5222YS Yellow
Lexmark C522 / C524	Lexmark C5222KS Black
Lexmark C522 / C524	Lexmark C5222CS Cyan
Lexmark C522 / C524	Lexmark C5222MS Magenta
Lexmark C522 / C524	Lexmark C5222YS Yellow
Lexmark C524 / C532DN / C534x	Lexmark C5240KH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5240CH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5240MH HC M
Lexmark C524 / C532DN / C534x	Lexmark C5240YH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5242KH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5242CH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5242MH Hi Cap
Lexmark C524 / C532DN / C534x	Lexmark C5242YH Hi Cap
Lexmark C534 / C5340CX Cyan	Lexmark C5340CX Cyan
Lexmark C534 / C5340MX Magenta	Lexmark C5340MX Magenta
Lexmark C534 / C5340YX Yellow	Lexmark C5340YX Yellow
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540 Series ALL Cyan
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540 Series ALL Black
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540 Series ALL Magenta
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540 Series ALL Yellow
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H1CG Cyan Hi Cap
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H1KG Black Hi Cap
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H1MG Magenta Hi Cap
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H1YG Yellow Hi Cap
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H2CG Cyan Hi Cap
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H2KG Black Hi Cap
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H2MG Magenta Hi Cap
Lexmark C540 / C543 / C544 / C546 / X543 / X544 / X546	Lexmark C540H2YG Yellow Hi Cap
Lexmark C720	Lexmark 15W0900
Lexmark C720	Lexmark 15W0901

Lexmark C720	Lexmark 15W0902
Lexmark C720	Lexmark 15W0903
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734 Series Black
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734 Series Magenta
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734 Series Cyan
Lexmark C734 / C736 / X734 / X736 / X738n	Lexmark C734 Series Yellow
Lexmark C736 / X736 / X738	Lexmark C736A Black
Lexmark C736 / X736 / X738	Lexmark C736A Cyan
Lexmark C736 / X736 / X738	Lexmark C736A Magenta
Lexmark C736 / X736 / X738	Lexmark C736A Yellow
Lexmark C746	Lexmark C746 Black
Lexmark C746	Lexmark C746 Cyan
Lexmark C746	Lexmark C746 Magenta
Lexmark C746	Lexmark C746 Yellow
Lexmark C748	Lexmark C748 Black
Lexmark C748	Lexmark C748 Cyan
Lexmark C748	Lexmark C748 Magenta
Lexmark C748	Lexmark C748 Yellow
Lexmark C750	Lexmark 10B042K Black
Lexmark C750	Lexmark 10B042C Cyan
Lexmark C750	Lexmark 10B042M Magenta
Lexmark C750	Lexmark 10B042Y Yellow
Lexmark C770DN / C770DTN / C770N / C770X / C772X	Lexmark C7700KS Std Cap
Lexmark C770DN / C770DTN / C770N / C770X / C772X	Lexmark C7700CS Std Cap
Lexmark C770DN / C770DTN / C770N / C770X / C772X	Lexmark C7700MS Std Cap
Lexmark C770DN / C770DTN / C770N / C770X / C772X	Lexmark C7700YS Std Cap
Lexmark C772DN / C772DTN / C772N	Lexmark C7720KX Hi Cap
Lexmark C772DN / C772DTN / C772N	Lexmark C7720CX Hi Cap
Lexmark C772DN / C772DTN / C772N	Lexmark C7720MKX Hi Cap
Lexmark C772DN / C772DTN / C772N	Lexmark C7720YX Hi Cap
Lexmark C780x / C782n / C782x	Lexmark C780 / C782 All Black
Lexmark C780x / C782n / C782x	Lexmark C780 / C782 All Cyan
Lexmark C780x / C782n / C782x	Lexmark C780 / C782 All Magenta
Lexmark C780x / C782n / C782x	Lexmark C780 / C782 All Yellow
Lexmark C780x / C782n / C782x	Lexmark C780H1KG HI CAP B
Lexmark C780x / C782n / C782x	Lexmark C780H1CG HI CAP C
Lexmark C780x / C782n / C782x	Lexmark C780H1MG HI CAP M
Lexmark C780x / C782n / C782x	Lexmark C780H1YG HI CAP Y
Lexmark C780x / C782n / C782x	Lexmark C782 / C782X2KG Ex C Black
Lexmark C780x / C782n / C782x	Lexmark C782 / C782X2CG Ex C Cyan
Lexmark C780x / C782n / C782x	Lexmark C782 / C782X2MG Ex C Magenta
Lexmark C780x / C782n / C782x	Lexmark C782 / C782X2YG Ex C Yellow
Lexmark C782 / C782X1KG Black	Lexmark C782 / C782X1KG Black
Lexmark C782 / C782X1CG Cyan	Lexmark C782 / C782X1CG Cyan
Lexmark C782 / C782X1MG Magenta	Lexmark C782 / C782X1MG Magenta
Lexmark C782 / C782X1KY Yellow	Lexmark C782 / C782X1KY Yellow
Lexmark C792	Lexmark C792A1KG Black
Lexmark C792	Lexmark C792A1CG Cyan
Lexmark C792	Lexmark C792A1MG Magenta
Lexmark C792	Lexmark C792A1YG Yellow
Lexmark C792	Lexmark C792X1KG Black
Lexmark C792	Lexmark C792X1CG Cyan
Lexmark C792	Lexmark C792X1MG Magenta
Lexmark C792	Lexmark C792X1YG Yellow
Lexmark C910 / C910N / C912 / X912E	Lexmark 12N0771 Black
Lexmark C910 / C910N / C912 / X912E	Lexmark 12N0768 Cyan
Lexmark C910 / C910N / C912 / X912E	Lexmark 12N0769 Magenta
Lexmark C910 / C910N / C912 / X912E	Lexmark 12N0770 Yellow
Lexmark CS310 / 410 / 510	Lexmark 702CK / 702HK / 702XK
Lexmark CS310 / 410 / 510	Lexmark 702CC / 702HC / 702XC
Lexmark CS310 / 410 / 510	Lexmark 702CM / 702HM / 702XM
Lexmark CS310 / 410 / 510	Lexmark 702CY / 702HY / 702XY
Lexmark CS310 / 410 / 510	Lexmark 702CK / 702HK / 702XK INTRO
Lexmark CS310 / 410 / 510	Lexmark 702CC / 702HC / 702XC INTRO
Lexmark CS310 / 410 / 510	Lexmark 702CM / 702HM / 702XM INTRO
Lexmark CS310 / 410 / 510	Lexmark 702CY / 702HY / 702XY INTRO
Laemark CX310 / 410 / 510	Lexmark 802CK / 802HCK / 802XCK
Laemark CX310 / 410 / 510	Lexmark 802CC / 802HCC / 802XCC
Laemark CX310 / 410 / 510	Lexmark 802CM / 802HCM / 802XCM
Laemark CX310 / 410 / 510	Lexmark 802CY / 802HCY / 802XCY
Laemark CX310 / 410 / 510	Lexmark 802CK / 802HCK / 802XCK INTRO
Laemark CX310 / 410 / 510	Lexmark 802CC / 802HCC / 802XCC INTRO

Laemark CX310 / 410 / 510	Lexmark 802CM / 802HCM / 802XCM INTRO
Laemark CX310 / 410 / 510	Lexmark 802CY / 802HCY / 802XCY INTRO
Lexmark CX410 / CX510	Lexmark 802 Black ALL
Lexmark CX410 / CX510	Lexmark 802 Cyan ALL
Lexmark CX410 / CX510	Lexmark 802 Magenta ALL
Lexmark CX410 / CX510	Lexmark 802 Yellow ALL
Lexmark MS310 / MS410 / MS510 / MS610 Series	Lexmark 502 Std Cap
Lexmark MS310 / MS410 / MS510 / MS610 Series	Lexmark 502H Hi Cap
Lexmark MS510 / MS610 Series	Lexmark 502UE or X Ultra Hi Cap
Lexmark MS810 / MS811 / MS812 Series	Lexmark 520UE / 522X Ultra Hi Cap
Lexmark MS810 / MS811 / MS812 Series	Lexmark 522 Std Cap
Lexmark MS810 / MS811 / MS812 Series	Lexmark 522H Hi Cap
Lexmark MX310 / MX410 / MX510 / MX511 / MX611	Lexmark 602 Std Cap
Lexmark MX310 / MX410 / MX510 / MX511 / MX611	Lexmark 602H Hi Cap
Lexmark MX310 / MX410	Lexmark 600UE or X Ultra Hi Cap
Lexmark MX710 / MX711 / MX810 / MX811 / MX812	Lexmark 622 Std Cap
Lexmark MX710 / MX711 / MX810 / MX811 / MX812	Lexmark 622H Hi Cap
Lexmark MX710 / MX711 / MX810 / MX811 / MX812	Lexmark 622UE or X or 620XA Ultra Hi Cap
Lexmark MS310/410/510/511/610 INTRO	Lexmark MS310/410/510/511/610 INTRO
Lexmark MX310/410/510/511/610 INTRO	Lexmark MX310/410/510/511/610 INTRO
Lexmark MS710/711/810/811/812 INTRO	Lexmark MS710/711/810/811/812 INTRO
Lexmark MX710/711/810/811/812 INTRO	Lexmark MX710/711/810/811/812 INTRO
Lexmark X864de 4	Lexmark X860H21G
Lexmark C920 / C920DN / C920DTN / C920N	Lexmark C9202KH Black
Lexmark C920 / C920DN / C920DTN / C920N	Lexmark C9202CH Cyan
Lexmark C920 / C920DN / C920DTN / C920N	Lexmark C9202MH Magenta
Lexmark C920 / C920DN / C920DTN / C920N	Lexmark C9202YH Yellow
Lexmark X925de / C925	Lexmark X925 / C925 All Black
Lexmark X925de / C925	Lexmark X925 / C925 All Cyan
Lexmark X925de / C925	Lexmark X925 / C925 All Magenta
Lexmark X925de / C925	Lexmark X925 / C925 All Yellow
Lexmark C930 / C930H2KG Black	Lexmark C930 / C930H2KG Black
Lexmark C930 / C930H2CG Cyan	Lexmark C930 / C930H2CG Cyan
Lexmark C930 / C930H2MG Megenta	Lexmark C930 / C930H2MG Megenta
Lexmark C930 / C930H2YG Yellow	Lexmark C930 / C930H2YG Yellow
Lexmark XS796	Lexmark 24B5832 Cyan Hi Cap
Lexmark XS796	Lexmark 24B5833 Magenta Hi Cap
Lexmark XS796	Lexmark 24B5834 Yellow Hi Cap
Lexmark XS796	Lexmark 24B5835 Black Hi Cap
Lexmark C2132 / XC2132 / XC2130	Lexmark 24B6008 Cyan
Lexmark C2132 / XC2132 / XC2130	Lexmark 24B6009 Margenta
Lexmark C2132 / XC2132 / XC2130	Lexmark 24B6010 Yellow
Lexmark C2132 / XC2132 / XC2130	Lexmark 24B6011 Black
Lexmark E120	Lexmark E120 ALL
Lexmark E120	Lexmark 12036SE
Lexmark E210	Lexmark 10S0150
Lexmark E220	Lexmark 12S0300
Lexmark E220	Lexmark 12S0400
Lexmark E230 / E232 / E330 / E332 / E340 / E342 + Others	Lexmark 12A8300
Lexmark E230 / E232 / E330 / E332 / E340 / E342 Drum	Lexmark 12A8302 Drum
Lexmark E230 / E232 / E330 / E332 / E340 / E342 + Others	Lexmark 12A8305
Lexmark E230 / E232 / E330 / E332	Lexmark 12A8400
Lexmark E230 / E232 / E330 / E332	Lexmark 12A8405
Lexmark E230 / E232 / E240 / E330 / E332 / E340 / E342n	Lexmark E24016SE
Lexmark E230 / E232 / E240 / E330 / E332 / E340 / E342n	Lexmark E24036SE
Lexmark E250 / 350 / 352 / 450	Lexmark E250A11E
Lexmark E250 / 350 / 352 / 450	Lexmark E250A21E
Lexmark E260	Lexmark E260A11E
Lexmark E260/360/460	Lexmark E260 / E360 / E460 ALL
Lexmark E260/360/460	Lexmark E260A31E
Lexmark E320 / E322	Lexmark 12A2260
Lexmark E320 / E322	Lexmark 08A0475
Lexmark E320 / E322	Lexmark 08A0476
Lexmark E320 / E322	Lexmark 08A0477
Lexmark E320 / E322	Lexmark 08A0478
Lexmark E321 / E323	Lexmark E321 / E323 ALL
Lexmark E321 / E323	Lexmark 12A7405
Lexmark E321 / E323	Lexmark 12A7305
Lexmark E321 / E323	Lexmark 12A7400
Lexmark E340	Lexmark E34016HE
Lexmark E340	Lexmark E340A11G
Lexmark E340/342/232/330/332	Lexmark E34036HE

Lexmark E340/342/232/330/332	Lexmark E34040HW
Lexmark E350 / E352	Lexmark E350 / E352 ALL
Lexmark E350/352 Toner	Lexmark E352H21E
Lexmark E352	Lexmark E352H11E
Lexmark E360	Lexmark E360H11E
Lexmark E360 / 460 High Yield Toner	Lexmark E360H21E
Lexmark E360 / 460 Ext High Yield Toner	Lexmark E360H31E
Lexmark E450	Lexmark E450A11E
Lexmark E450	Lexmark E450A21E
Lexmark E450	Lexmark E450H11E
Lexmark E450	Lexmark E450H21E
Lexmark E460	Lexmark E460X11E
Lexmark E460 Extra High Yield Toner	Lexmark E460X21E
Lexmark E460	Lexmark E460X31E
Lexmark Optra E (Drum)	Lexmark 69G8257 Drum
Lexmark Optra E (Toner)	Lexmark 69G8256
Lexmark Optra M / M410 / M412	Lexmark 17G0152 Low User
Lexmark Optra M / M410 / M412	Lexmark 17G0154 Hi Cap
Lexmark Optra M / M410 / M412	Lexmark 4K00199 Std Cap
Lexmark Optra S (Prebate)	Lexmark 1382620
Lexmark Optra S (Prebate)	Lexmark 1382625
Lexmark Optra S (Non Prebate)	Lexmark 1382920
Lexmark Optra S (Non Prebate)	Lexmark 1382925
Lexmark Optra S (Prebate)	Lexmark 12A0150 Hi Cap
Lexmark Optra SE 3455 12A0725	Lexmark Optra SE3455 ALL
Lexmark Optra SE 3455	Lexmark 12A0825
Lexmark Optra SE 3455	Lexmark 12A0829
Lexmark SC 1275	Lexmark 1361751
Lexmark SC 1275	Lexmark 1361752
Lexmark SC 1275	Lexmark 1361753
Lexmark SC 1275	Lexmark 1361754
Lexmark T420	Lexmark 12A7310
Lexmark T420	Lexmark 12A7315
Lexmark T420	Lexmark 12A8544
Lexmark T420	Lexmark 12A8644
Lexmark T420	Lexmark T420 ALL
Lexmark T420	Lexmark 12A7415
Lexmark X422 MFP	Lexmark 12A3710
Lexmark X422	Lexmark 12A4715
Lexmark T430 12A8420	Lexmark T430 12A8420
Lexmark T430 12A8425	Lexmark T430 12A8425
Lexmark T430 12A8320	Lexmark T430 12A8320
Lexmark T430 12A8325	Lexmark T430 12A8325
Lexmark X463 / X463A11G	Lexmark X463A11G
Lexmark X463 / X463H11G	Lexmark X463H11G
Lexmark X463 / X463X11G	Lexmark X463X11G
Lexmark X463 / X463X31G	Lexmark X463X31G
Lexmark T520 / T522	Lexmark T520 / T522 ALL
Lexmark T520 / T522 / X520 / X522	Lexmark 12A6730
Lexmark T520 / T522 / X520 / X522	Lexmark 12A6735
Lexmark T520 / T522 / X520 / X523	Lexmark 12A6830
Lexmark T520 / T522, X520, X522 High Yield	Lexmark 12A6835 Hi Cap
Lexmark T520 / T522, X520, X522 High Yield	Lexmark 12A6839 Hi Cap
Lexmark T610 / T612 / T614 / T616n	Lexmark 12A6844
Lexmark T610 / T612 / T614 / T616n	Lexmark 12A5845
Lexmark T610 / T612 / T614 / T616n	Lexmark T610 ALL
Lexmark T610 / T612 / T614 / T616n	Lexmark 12A5740
Lexmark T610 / T612 / T614 / T616n	Lexmark 12A5745
Lexmark T610 / T612 / T614 / T616n	Lexmark 12A5840
Lexmark T610 / T612 / T614 / T616n	Lexmark 12A5849
Lexmark T620 / T622 / X620	Lexmark 12A6160 Hi Cap
Lexmark T620 / T622 / X620	Lexmark 12A7644
Lexmark T620 / T622 / X620e	Lexmark 12A6865
Lexmark T620 / T622 12A6760	Lexmark T620 / T622 ALL
Lexmark T620 / T622 / X620e / 12A6765	Lexmark 12A6765
Lexmark T620 / T622 / X620e / 12A6860	Lexmark 12A6860
Lexmark T620 / T622 / X620e / 12A6869	Lexmark 12A6869
Lexmark T630	Lexmark 12A7612
Lexmark X630	Lexmark X630
Lexmark T630	Lexmark T630/2/4 ALL
Lexmark T630	Lexmark 12A7462
Lexmark T630	Lexmark 12A7360

Lexmark T630	Lexmark 12A7362
Lexmark T632 / T634 / X632	Lexmark 12A7610 Ex Hi Cap
Lexmark T630	Lexmark 12A8044
Lexmark T632 / T634 / X632	Lexmark 12A7465 Ex Hi Cap
Lexmark T630	Lexmark 12A7365
Lexmark T640 / T642 / T644 / 64040HW High Cap	Lexmark 64040HW Double Slot
Lexmark T640/T642/T644/X640E/X642E/X644E/X646E	Lexmark 64080HW
Lexmark T640 / T642 / T644n	Lexmark 64016HE Single Slot
Lexmark T640 / T642 / T644n	Lexmark 64440XW Ex Hi Cap
Lexmark X642e / X644 High Yield	Lexmark X642H31E
Lexmark X644 / X644A11E	Lexmark X644A11E
Lexmark X644 / X644H11E	Lexmark X644H11E
Lexmark X644 / X644X11E	Lexmark X644X11E
Lexmark X644 Extra High Yield	Lexmark X644X31E
Lexmark T652	Lexmark T650 / 652 / 654 ALL INTRO
Lexmark T650 / T650A11E	Lexmark T650A11E
Lexmark T650 / 652 / 654 Standard Yield	Lexmark T650A21E
Lexmark T650 / T650H11E	Lexmark T650H11E
Lexmark T650 / 652 / 654 High Yield	Lexmark T650H21E
Lexmark T650 / T652 / T654	Lexmark T650H31E HC
Lexmark T654	Lexmark T654X11A
Lexmark T654	Lexmark T654 / T654X11E
Lexmark T654 Extra High Yield	Lexmark T654X21A
Lexmark T654 / T654X21E	Lexmark T654X21E Ex Hi Cap Black
Lexmark T654 Extra High Yield	Lexmark T654X31E
Lexmark W820	Lexmark 12B0090
Lexmark X203n / X204n	Lexmark X203 / X204
Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264A11G SC
Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264A21G SC
Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264H11G HC
Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264H21G HC
Lexmark X264dn / X363dn / X364dn / X364dw	Lexmark X264H31G HC
Lexmark X340	Lexmark X340H22G Drum
Lexmark X340 / X340A21G	Lexmark X340A21G
Lexmark X340	Lexmark X340H11G
Lexmark X340 / E342e Toner	Lexmark E340A21G
Lexmark X651 / X651A11E	Lexmark X651A11E
Lexmark X651 / X651H11E	Lexmark X651H11E
Lexmark X651/652/654/656/658 High Yield	Lexmark X651A21E
Lexmark X651/652/654/656/658 High Yield	Lexmark X651H21E
Lexmark X651/652/654/656/658 High Yield	Lexmark X651H31E
Lexmark X654 / 656 / 658 Extra High Yield	Lexmark X654X21E
Lexmark X654 / X654X11E	Lexmark X654X11E
Lexmark X654X31E	Lexmark X654X31E Ex Hi Cap Black
Lexmark W840	Lexmark W84020H
Remanufactured / Refilled Lexmark Laser Printers	Remanufactured / Refilled Lexmark Laser Printers
Lexmark MS810 / MS811 / MS812 Series	Lexmark 520UE / 522X Ultra Hi Cap (REMAN)
Lexmark E260/360/460	Lexmark E260 / E360 / E460 ALL (REMAN)
OKI Fax & Laser Printers	OKI Fax & Laser Printers
OKI Executive Series 6410	OKI 01272901 / ES6410 Yellow Drum
OKI Executive Series 6410	OKI 01272902 / ES6410 Magenta Drum
OKI Executive Series 6410	OKI 01272903 / ES6410 Cyan Drum
OKI Executive Series 6410	OKI 01272904 / ES6410 Black Drum
OKI B710/B720/B730	OKI 01279001 / B710
OKI C5550 / C5800 / C5900	OKI 42918105 C9600 / C9800 Yellow Drum
OKI C9600/C9650/C9800/C9850 Drum	OKI 42918105 C9600 / C9800 Yellow Drum
OKI C9600/C9650/C9800/C9850 Drum	OKI 42918106 C9600 / C9800 Magenta Drum
OKI C5550 / C5800 / C5900	OKI 42918106 C9600 / C9800 Magenta Drum
OKI C9600/C9650/C9800/C9850 Drum	OKI 42918107 C9600 / C9800 Cyan Drum
OKI C5550 / C5800 / C5900	OKI 42918107 C9600 / C9800 Cyan Drum
OKI C9600/C9650/C9800/C9850 Drum	OKI 42918108 C9600 / C9800 Black Drum
OKI C5550 / C5800 / C5900	OKI 42918108 C9600 / C9800 Black Drum
OKI C9600/C9650/C9800/C9850	OKI 42918913 C9600 / C9800 Yellow
OKI C9600/C9650/C9800/C9850	OKI 42918914 C9600 / C9800 Magenta
OKI C9600/C9650/C9800/C9850	OKI 42918915 C9600 / C9800 Cyan
OKI C9600/C9650/C9800/C9850	OKI 42918916 C9600 / C9800 Black
OKI C5600 / 5700	OKI 43324408 C5600 / C5700 Black
OKI C5550 / C5800 / C5900	OKI 43324421 C5550 / C5800 / C5900 Yellow
OKI C5550 / C5800 / C5900	OKI 43324422 C5550 / C5800 / C5900 Magenta
OKI C5550 / C5800 / C5900	OKI 43324423 C5550 / C5800 / C5900 Cyan
OKI C5550 / C5800 / C5900	OKI 43324424 C5550 / C5800 / C5900 Black
OKI C5600 / 5700	OKI 43381705 C5600 / C5700 Yellow Drum

OKI C5600 / 5700	OKI 43381706 C5600 / C5700 Magenta Drum
OKI C5600 / 5700	OKI 43381707 C5600 / C5700 Cyan Drum
OKI C5600 / 5700	OKI 43381708 C5600 / C5700 Black Drum
OKI C5600 / 5700	OKI 43381905 C5600 / C5700 Yellow
OKI C5600 / 5700	OKI 43381906 C5600 / C5700 Magenta
OKI C5600 / 5700	OKI 43381907 C5600 / C5700 Cyan
OKI C8600 / 8800 Drum	OKI 43449013 C8600 / C8800 Yellow Drum
OKI C8600 / 8800 Drum	OKI 43449014 C8600 / C8800 Magenta Drum
OKI C8600 / 8800 Drum	OKI 43449015 C8600 / C8800 Cyan Drum
OKI C8600 / 8800 Drum	OKI 43449016 C8600 / C8800 Black Drum
OKI C8600 / 8800	OKI 43487709 / C8600 / C8800 Yellow
OKI C8600 / 8800	OKI 43487710 / C8600 / C8800 Magenta
OKI C8600 / 8800	OKI 43487711 / C8600 / C8800 Cyan
OKI C8600 / 8800	OKI 43487712 / C8600 / C8800 Black
OKI C5650 / C5750	OKI 43865708 C5650 / C5750 Black
OKI C710 / C711 Yellow	OKI 43866105 / C710 / C711 Yellow
OKI C710 / C711 Magenta	OKI 43866106 / C710 / C711 Magenta
OKI C710 / C711 Cyan	OKI 43866107 / C710 / C711 Cyan
OKI C710 / C711 Black	OKI 43866108 / C710 / C711 Black
OKI C5650 / C5750	OKI 43870005 C5650 / C5750 Yellow Drum
OKI C5650 / C5750	OKI 43870006 C5650 / C5750 Magenta Drum
OKI C5650 / C5750	OKI 43870007 C5650 / C5750 Cyan Drum
OKI C5650 / C5750	OKI 43870008 C5650 / C5750 Black Drum
OKI C5650 / C5750	OKI 43872305 C5650 / C5750 Yellow
OKI C5650 / C5750	OKI 43872306 C5650 / C5750 Magenta
OKI C5650 / C5750	OKI 43872307 C5650 / C5750 Cyan
OKI Executive Series 6410	OKI 44315317 / ES6410 Yellow
OKI Executive Series 6410	OKI 44315318 / ES6410 Magenta
OKI Executive Series 6410	OKI 44315319 / ES6410 Cyan
OKI Executive Series 6410	OKI 44315320 / ES6410 Black
OKI C710 / C711 Yellow	OKI 44318505 / C710 / C711 Yellow Drum
OKI C710 / C711 Magenta	OKI 44318506 / C710 / C711 Magenta Drum
OKI C710 / C711 Cyan	OKI 44318507 / C710 / C711 Cyan Drum
OKI C710 / C711 Black	OKI 44318508 / C710 / C711 Black Drum
OKI B411/B431/MB471	OKI 44574302 / B411 / B431 Drum
OKI B411/B431/MB471	OKI 44574702 / 602 B411 / B431
Oki B840/B840dn/B840dtn/B840n	OKI 44661802 Black
OKI C831 / C841	OKI 44844505 C831 / C841 Yellow
OKI C831 / C841	OKI 44844506 C831 / C841 Magenta
OKI C831 / C841	OKI 44844507 C831 / C841 Cyan
OKI C831 / C841	OKI 44844508 C831 / C841 Black
OKI C822 Yellow	OKI 44844613 / C822 Yellow
OKI C822 Magenta	OKI 44844614 / C822 Magenta
OKI C822 Cyan	OKI 44844615 / C822 Cyan
OKI C822 Black	OKI 44844616 / C822 Black
Oki C301/C321/MC332/MC342	OKI 44973533 Yellow
Oki C301/C321/MC332/MC342	OKI 44973534 Magenta
Oki C301/C321/MC332/MC342	OKI 44973535 Cyan
Oki C301/C321/MC332/MC342	OKI 44973536 Black
OKI C911dn / C931 / C931dn	OKI 45103713 / C931 Yellow Drum
OKI C911dn / C931 / C931dn	OKI 45103714 / C931 Magenta Drum
OKI C911dn / C931 / C931dn	OKI 45103715 / C931 Cyan Drum
OKI C911dn / C931 / C931dn	OKI 45103716 / C931 Black Drum
Oki B731dnw / MB770 / MB770dfn / MB770dn	OKI 45439002 B731 Black Hi Cap
Oki MB760 and MB770	OKI 45456305 Drum
OKI B721/731d/MB760/770	OKI 45488802 / B721
OKI B412d / B432 / B512 / MB472/ MB492/ MB562	OKI 45807102 / B412 Black Std Cap
OKI B412d / B432 / B512 / MB472/ MB492/ MB562	OKI 45807106 / 45807111 B412 Black Hi Cap
OKI B2500 MFP/B2520/B2540/OKIFAX 2510/2530	OKI B2500 / 09004447
OKI B6200 / B6250	OKI B6200 / B6250 09004078
OKI B6300 / 09004079 Black	OKI B6300 / 09004079 Black
OKI B6500	OKI B6500 / 09004461 Black Std Cap
OKI B6500	OKI B6500 / 09004462 Black Hi Cap
OKI C931 / C931dn	OKI Black 45536508 Hi Cap
OKI C110 / C130 / MC160n	OKI C110 / C130n Black Drum
OKI C110 / C130 / MC160n	OKI C110 / C130n Cyan Drum
OKI C110 / C130 / MC160n	OKI C110 / C130n Hi Cap Black
OKI C110 / C130 / MC160n	OKI C110 / C130n Hi Cap Cyan
OKI C110 / C130 / MC160n	OKI C110 / C130n Hi Cap Magenta
OKI C110 / C130 / MC160n	OKI C110 / C130n Hi Cap Yellow
OKI C110 / C130 / MC160n	OKI C110 / C130n Magenta Drum
OKI C110 / C130 / MC160n	OKI C110 / C130n Std Cap Black

OKI C110 / C130 / MC160n	OKI C110 / C130n Std Cap Cyan
OKI C110 / C130 / MC160n	OKI C110 / C130n Std Cap Magenta
OKI C110 / C130 / MC160n	OKI C110 / C130n Std Cap Yellow
OKI C110 / C130 / MC160n	OKI C110 / C130n Yellow Drum
OKI C310dn / C330dn / C510dn / C530dn / MC351 / MC361 / MC561	OKI C310 / C530 44469706 Black
OKI C310dn / C330dn / C510dn / C530dn / MC351 / MC361 / MC561	OKI C310 / C530 44469722 Yellow
OKI C310dn / C330dn / C510dn / C530dn / MC351 / MC361 / MC561	OKI C310 / C530 44469723 Magenta
OKI C310dn / C330dn / C510dn / C530dn / MC351 / MC361 / MC561	OKI C310 / C530 44469724 Cyan
OKI C931 / C931dn	OKI Cyan 45536507 Hi Cap
OKI C931 / C931dn	OKI Magenta 45536506 Hi Cap
OKI C931 / C931dn	OKI Yellow 45536505 Hi Cap
Remanufactured / Refilled OKI Fax & Laser Printers	Remanufactured / Refilled OKI Fax & Laser Printers
Panasonic Fax & Laser Printers	Panasonic Fax & Laser Printers
Panafax UF-4100 / UF-490	Panafax UG-3221
Panafax UF585 / UF595	Panafax UG-3350
Panafax DX-600/UF-580/UF-585/UF-590/UF-595/UF-6100/UF-6300	Panafax UG-3380
Panafax UF7100 / UF8100	Panafax UG-5545
Remanufactured / Refilled Panasonic Fax & Laser Printers	Remanufactured / Refilled Panasonic Fax & Laser Printer
Ricoh Fax & Laser Printers	Ricoh Fax & Laser Printers
Ricoh SP C811dn	Ricoh 884201 Black
Ricoh SP C811dn	Ricoh 884202 Yellow
Ricoh SP C811dn	Ricoh 884203 Magenta
Ricoh SP C811dn	Ricoh 884204 Cyan
Ricoh Aficio MP C2000/2500/3000 Black	Ricoh MP C2000/2500/3000 Black
Ricoh Aficio MP C2000/2500/3000 Cyan	Ricoh MP C2000/2500/3000 Cyan
Ricoh Aficio MP C2000/2500/3000 Magenta	Ricoh MP C2000/2500/3000 Magenta
Ricoh Aficio MP C2000/2500/3000 Yellow	Ricoh MP C2000/2500/3000 Yellow
Ricoh Aficio MP C2003SP / C2503SP	Ricoh MP C2003SP / C2503 Black
Ricoh Aficio MP C2003SP / C2503SP	Ricoh MP C2003SP / C2503 Cyan
Ricoh Aficio MP C2003SP / C2503SP	Ricoh MP C2003SP / C2503 Magenta
Ricoh Aficio MP C2003SP / C2503SP	Ricoh MP C2003SP / C2503 Yellow
Ricoh Aficio MP C2800 / C3300	Ricoh MP C2800 / C3300 Black
Ricoh Aficio MP C2800 / C3300	Ricoh MP C2800 / C3300 Cyan
Ricoh Aficio MP C2800 / C3300	Ricoh MP C2800 / C3300 Magenta
Ricoh Aficio MP C2800 / C3300	Ricoh MP C2800 / C3300 Yellow
Ricoh Aficio MP C3500/4500 Black	Ricoh MP C3500/4500 Black
Ricoh Aficio MP C3500/4500 Cyan	Ricoh MP C3500/4500 Cyan
Ricoh Aficio MP C3500/4500 Magenta	Ricoh MP C3500/4500 Magenta
Ricoh Aficio MP C3500/4500 Yellow	Ricoh MP C3500/4500 Yellow
Ricoh Aficio MP C4000/5000 Black	Ricoh MP C4000/5000 Black
Ricoh Aficio MP C4000/5000 Cyan	Ricoh MP C4000/5000 Cyan
Ricoh Aficio MP C4000/5000 Magenta	Ricoh MP C4000/5000 Magenta
Ricoh Aficio MP C4000/5000 Yellow	Ricoh MP C4000/5000 Yellow
Ricoh Aficio MP C3003SP / C3503SP	Ricoh 841829 Black
Ricoh Aficio MP C3003SP / C3503SP	Ricoh 841832 Cyan
Ricoh Aficio MP C3003SP / C3503SP	Ricoh 841831 Magenta
Ricoh Aficio MP C3003SP / C3503SP	Ricoh 841830 Yellow
Ricoh Aficio MP C4503SP/C5503SP/C6003SP	Ricoh 841865 Black
Ricoh Aficio MP C4503SP/C5503SP/C6003SP	Ricoh 841868 Cyan
Ricoh Aficio MP C4503SP/C5503SP/C6003SP	Ricoh 841867 Magenta
Ricoh Aficio MP C4503SP/C5503SP/C6003SP	Ricoh 841866 Yellow
Ricoh Aficio MP C2030 / C2050 / C2550	Ricoh MP C2550E Black
Ricoh Aficio MP C2030 / C2050 / C2550	Ricoh MP C2550E Cyan
Ricoh Aficio MP C2030 / C2050 / C2550	Ricoh MP C2550E Magenta
Ricoh Aficio MP C2030 / C2050 / C2550	Ricoh MP C2550E Yellow
Ricoh Aficio AP400 Type 220 / 400943	Ricoh AP400 / 400943
Ricoh Aficio SP 201N / 204SF	Ricoh 407256
Ricoh Aficio SP C220N / C221N / C222DN	Ricoh SP C220 Black
Ricoh Aficio SP C220N / C221N / C222DN	Ricoh SP C220 Cyan
Ricoh Aficio SP C220N / C221N / C222DN	Ricoh SP C220 Magenta
Ricoh Aficio SP C220N / C221N / C222DN	Ricoh SP C220 Yellow
Ricoh Aficio SP C220N / C221N / C222DN	Ricoh SP C220 Black INTRO
Ricoh Aficio SP C220N / C221N / C222DN	Ricoh SP C220 Cyan INTRO
Ricoh Aficio SP C220N / C221N / C222DN	Ricoh SP C220 Magenta INTRO
Ricoh Aficio SP C220N / C221N / C222DN	Ricoh SP C220 Yellow INTRO
Ricoh Aficio SP C250	Ricoh SP C250 Black
Ricoh Aficio SP C250	Ricoh SP C250 Cyan
Ricoh Aficio SP C250	Ricoh SP C250 Magenta
Ricoh Aficio SP C250	Ricoh SP C250 Yellow
Ricoh Aficio SP C252 HE	Ricoh SP C252HE Black
Ricoh Aficio SP C252 HE	Ricoh SP C252HE Cyan

Ricoh Aficio SP C252 HE	Ricoh SP C252HE Magenta
Ricoh Aficio SP C252 HE	Ricoh SP C252HE Yellow
Ricoh Aficio SP C252 HE	Ricoh SP C252HE Black INTRO
Ricoh Aficio SP C252 HE	Ricoh SP C252HE Cyan INTRO
Ricoh Aficio SP C252 HE	Ricoh SP C252HE Magenta INTRO
Ricoh Aficio SP C252 HE	Ricoh SP C252HE Yellow INTRO
Ricoh SP C310HE	Ricoh SP C310HE Black
Ricoh SP C310HE	Ricoh SP C310HE Cyan
Ricoh SP C310HE	Ricoh SP C310HE Magenta
Ricoh SP C310HE	Ricoh SP C310HE Yellow
Ricoh SP C310HE	Ricoh SP C310HE Black INTRO
Ricoh SP C310HE	Ricoh SP C310HE Cyan INTRO
Ricoh SP C310HE	Ricoh SP C310HE Magenta INTRO
Ricoh SP C310HE	Ricoh SP C310HE Yellow INTRO
Ricoh Aficio SP 100e/112/112SF/112SU	Ricoh 407166 SP 150
Ricoh SP 150/150SU/150SUw/150w	Ricoh 407971 150 Black Std Cap
Ricoh SP 150/150SU/150SUw/150w	Ricoh 408010 150 Black Hi Cap
Ricoh SP 311 407246 / 407249	Ricoh SP 311 407246 / 407249
Ricoh Aficio SP 1000S / Ricoh Fax 1140L / 1180L	Ricoh SP 1000E (413196)
Ricoh SP 3400/3401	Ricoh SP 3400 / 3401
Ricoh Aficio SP3500 / SP3510	Ricoh SP 3500 / SP3510
Ricoh SP 3600DN/3600SF/3610/4510DN/4510SF	Ricoh SP 3600/3610/4510
Ricoh SP 3600DN/3600SF/3610/4510DN/4510SF	Ricoh SP 3600/3610/4510 407324 Drum
Ricoh Aficio SP4100N / SP4110N / SP4210N / SP4310N	Ricoh SP 4100 (403073)
Ricoh Aficio SP 5100E	Ricoh SP 5100E / 402858
Ricoh Aficio SP 6330N	Ricoh SP 6330N / 406649
Remanufactured / Refilled Ricoh Fax & Laser Printers	
Remanufactured / Refilled Ricoh Fax & Laser Printers	
Samsung Laser Printers	
Samsung Laser Printers	
Samsung CLP-510 Black	Samsung CLP 510 Black
Samsung CLP-510 Cyan	Samsung CLP 510 Cyan
Samsung CLP-510 Magenta	Samsung CLP 510 Magenta
Samsung CLP-510 Yellow	Samsung CLP 510 Yellow
Samsung SL-C430/SL-C480	Samsung CLT 404S Black
Samsung SL-C430/SL-C480	Samsung CLT 404S Cyan
Samsung SL-C430/SL-C480	Samsung CLT 404S Magenta
Samsung SL-C430/SL-C480	Samsung CLT 404S Yellow
Samsung SL-C430/SL-C480	Samsung CLT 404S Black INTRO
Samsung SL-C430/SL-C480	Samsung CLT 404S Cyan INTRO
Samsung SL-C430/SL-C480	Samsung CLT 404S Magenta INTRO
Samsung SL-C430/SL-C480	Samsung CLT 404S Yellow INTRO
Samsung CLT 406 Black INTRO	Samsung CLT 406 Black INTRO
Samsung CLT 406 Cyan INTRO	Samsung CLT 406 Cyan INTRO
Samsung CLT 406 Magenta INTRO	Samsung CLT 406 Magenta INTRO
Samsung CLT 406 Yellow INTRO	Samsung CLT 406 Yellow INTRO
Samsung CLT 406S Black	Samsung CLT 406S Black
Samsung CLT 406S Cyan	Samsung CLT 406S Cyan
Samsung CLT 406S Magenta	Samsung CLT 406S Magenta
Samsung CLT 406S Yellow	Samsung CLT 406S Yellow
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT 4072 Black INTRO
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT 4072 Cyan INTRO
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT 4072 Magenta INTRO
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT 4072 Yellow INTRO
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT 4072S Black
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT 4072S Cyan
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT 4072S Magenta
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT 4072S Yellow
Samsung CLP-310 / 315 / CLX 3170fn / 3175	Samsung CLT 4092 Black INTRO
Samsung CLP-310 / 315 / CLX 3170fn / 3175	Samsung CLT 4092 Cyan INTRO
Samsung CLP-310 / 315 / CLX 3170fn / 3175	Samsung CLT 4092 Magenta INTRO
Samsung CLP-310 / 315 / CLX 3170fn / 3175	Samsung CLT 4092 Yellow INTRO
Samsung CLP-310 / 315 / CLX 3170fn / 3175	Samsung CLT 4092 Back
Samsung CLP-310 / 315 / CLX 3170fn / 3175	Samsung CLT 4092 Cyan
Samsung CLP-310 / 315 / CLX 3170fn / 3175	Samsung CLT 4092 Magenta
Samsung CLP-310 / 315 / CLX 3170fn / 3175	Samsung CLT 4092 Yellow
Samsung ProXpress SL-C3010ND/SL-C3060FR/SL-C3060ND	Samsung CLT 503L Black
Samsung ProXpress SL-C3010ND/SL-C3060FR/SL-C3060ND	Samsung CLT 503L Cyan
Samsung ProXpress SL-C3010ND/SL-C3060FR/SL-C3060ND	Samsung CLT 503L Magenta
Samsung ProXpress SL-C3010ND/SL-C3060FR/SL-C3060ND	Samsung CLT 503L Yellow
Samsung CLP-415/CLX-4195/SL-C1810/C1860/C1860	Samsung CLT 504 Black INTRO
Samsung CLP-415/CLX-4195/SL-C1810/C1860/C1860	Samsung CLT 504 Cyan INTRO
Samsung CLP-415/CLX-4195/SL-C1810/C1860/C1860	Samsung CLT 504 Magenta INTRO
Samsung CLP-415/CLX-4195/SL-C1810/C1860/C1860	Samsung CLT 504 Yellow INTRO

Samsung CLP-415/CLX-4195/SL-C1810/C1860/C1860	Samsung CLT 504S Black
Samsung CLP-415/CLX-4195/SL-C1810/C1860/C1860	Samsung CLT 504S Cyan
Samsung CLP-415/CLX-4195/SL-C1810/C1860/C1860	Samsung CLT 504S Magenta
Samsung CLP-415/CLX-4195/SL-C1810/C1860/C1860	Samsung CLT 504S Yellow
Samsung C2620DW / C2670FW / SL-C2620DW / SL-C2670FW	Samsung CLT 505L Black
Samsung C2620DW / C2670FW / SL-C2620DW / SL-C2670FW	Samsung CLT 505L Cyan
Samsung C2620DW / C2670FW / SL-C2620DW / SL-C2670FW	Samsung CLT 505L Magenta
Samsung C2620DW / C2670FW / SL-C2620DW / SL-C2670FW	Samsung CLT 505L Yellow
Samsung C2620DW / C2670FW / SL-C2620DW / SL-C2670FW	Samsung CLT 505 Black INTRO
Samsung C2620DW / C2670FW / SL-C2620DW / SL-C2670FW	Samsung CLT 505 Cyan INTRO
Samsung C2620DW / C2670FW / SL-C2620DW / SL-C2670FW	Samsung CLT 505 Magenta INTRO
Samsung C2620DW / C2670FW / SL-C2620DW / SL-C2670FW	Samsung CLT 505 Yellow INTRO
Samsung CLP-680ND / CLX-6260	Samsung CLT 506L Black Hi Cap
Samsung CLP-680ND / CLX-6260	Samsung CLT 506L Cyan Hi Cap
Samsung CLP-680ND / CLX-6260	Samsung CLT 506L Magenta Hi Cap
Samsung CLP-680ND / CLX-6260	Samsung CLT 506L Yellow Hi Cap
Samsung CLP-680ND / CLX-6260	Samsung CLT 506 Black INTRO
Samsung CLP-680ND / CLX-6260	Samsung CLT 506 Cyan INTRO
Samsung CLP-680ND / CLX-6260	Samsung CLT 506 Magenta INTRO
Samsung CLP-680ND / CLX-6260	Samsung CLT 506 Yellow INTRO
Samsung CLP-680ND / CLX-6260	Samsung CLT 506S Black Std Cap
Samsung CLP-680ND / CLX-6260	Samsung CLT 506S Cyan Std Cap
Samsung CLP-680ND / CLX-6260	Samsung CLT 506S Magenta Std Cap
Samsung CLP-680ND / CLX-6260	Samsung CLT 506S Yellow Std Cap
Samsung CLP-620 / CLP-670 / CLX-6220FX / CLX-6250FX	Samsung CLT 5082L Black
Samsung CLP-620 / CLP-670 / CLX-6220FX / CLX-6250FX	Samsung CLT 5082L Cyan
Samsung CLP-620 / CLP-670 / CLX-6220FX / CLX-6250FX	Samsung CLT 5082L Magenta
Samsung CLP-620 / CLP-670 / CLX-6220FX / CLX-6250FX	Samsung CLT 5082L Yellow
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT 6062S Black
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT 6062S Cyan
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT 6062S Magenta
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT 6062S Yellow
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT 6072S Cyan
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT 6072S Magenta
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT 6072S Yellow
Samsung CLP-770 / 775	Samsung CLT 6092S Black
Samsung CLX-8640ND/8650ND/MultiXpress C8640ND/C8650ND	Samsung CLT 659S Black
Samsung CLX-8640ND/8650ND/MultiXpress C8640ND/C8650ND	Samsung CLT 659S Cyan
Samsung CLX-8640ND/8650ND/MultiXpress C8640ND/C8650ND	Samsung CLT 659S Magenta
Samsung CLX-8640ND/8650ND/MultiXpress C8640ND/C8650ND	Samsung CLT 659S Yellow
Samsung MultiXpress X7400/X7500/X7600	Samsung CLT 806S Black
Samsung MultiXpress X7400/X7500/X7600	Samsung CLT 806S Cyan
Samsung MultiXpress X7400/X7500/X7600	Samsung CLT 806S Magenta
Samsung MultiXpress X7400/X7500/X7600	Samsung CLT 806S Yellow
Samsung MultiXpress X K4250RX/K4300LX/4220RX/4250LX/4300LX	Samsung CLT 808S Black
Samsung MultiXpress X K4250RX/K4300LX/4220RX/4250LX/4300LX	Samsung CLT 808S Cyan
Samsung MultiXpress X K4250RX/K4300LX/4220RX/4250LX/4300LX	Samsung CLT 8068 Magenta
Samsung MultiXpress X K4250RX/K4300LX/4220RX/4250LX/4300LX	Samsung CLT 8068 Yellow
Samsung CLX-9201NA / 9251NA / 9301NA	Samsung CLT 809S Black
Samsung CLX-9201NA / 9251NA / 9301NA	Samsung CLT 809S Cyan
Samsung CLX-9201NA / 9251NA / 9301NA	Samsung CLT 809S Magenta
Samsung CLX-9201NA / 9251NA / 9301NA	Samsung CLT 809S Yellow
Samsung ML-2160 / 2162 / 2165 / 2168 / SCX-3400 / 3405 / SF-760P	Samsung MLT D101 INTRO
Samsung ML-2950 / ML-2955 / SCX-4729	Samsung MLT D103 INTRO
Samsung Xpress M2675 / M2825/ M2875FD	Samsung MLT D116 INTRO
Samsung ML-2010 / ML-2015 / ML-2510 / ML-2570 / ML-2571N	Samsung MLT D119S INTRO
Samsung ML-3750ND	Samsung MLT D305 INTRO
Samsung ML 4510ND / ML 4512ND / ML5012ND	Samsung MLT D307 INTRO
Samsung ML-5510ND / ML-6510ND	Samsung MLT D309 INTRO
Samsung ML-2160 / 2162 / 2165 / 2168 / SCX-3400 / 3405 / SF-760P	Samsung MLT D101S
Samsung ML-2950 / ML-2955 / SCX-4729	Samsung MLT D103L Hi Cap
Samsung ML-2950 / ML-2955 / SCX-4729	Samsung MLT D103S Std Cap
Samsung ML-1660 / ML-1665 / ML-1860 / ML-1865W / SCX-3205 / 3205W	Samsung MLT D1042S
Samsung ML-1660 / ML-1665 / ML-1860 / ML-1865W / SCX-3205 / 3205W	Samsung MLT D1042SX
Samsung ML-1910 / 1915 / 2525 / 2580 / SCX-4600 / 4623 / SF-650	Samsung MLT D1052L Hi Cap
Samsung ML-1910 / 1915 / 2525 / 2580 / SCX-4600 / 4623 / SF-650	Samsung MLT D1052S Std Cap
Samsung ML-1640 / 2240 / 2241	Samsung MLT D1082S
Samsung SCX-4300	Samsung MLT D1092S
Samsung Xpress SL-M2020W / M2022 / M2070	Samsung MLT D111 INTRO
Samsung Xpress SL-M2020W / M2022 / M2070	Samsung MLT D111S
Samsung Xpress SL-M2020W / M2022 / M2070	Samsung MLT D111L
Samsung Xpress M2675 / M2825/ M2875FD	Samsung MLT D116L Hi Cap

Samsung Xpress M2675 / M2825/ M2875FD	Samsung MLT D116S Std Cap
Samsung SCX-4655F / 4655FN	Samsung MLT D117S Std Cap
Samsung SCX-4655F / 4655FN	Samsung MLT D117S INTRO
Samsung ML-2010 / ML-2015 / ML-2510 / ML-2570 / ML-2571N	Samsung MLT D119S
Samsung SL-M4030ND / SL-M4080FX	Samsung MLT D201L Hi Cap
Samsung SL-M4030ND / SL-M4080FX	Samsung MLT D201S Std Cap
Samsung SL-M3320/M3370/M3820/M3870/M4020/M4070	Samsung MLT D203 INTRO
Samsung SL-M3320/M3370/M3820/M3870/M4020/M4070	Samsung MLT D203E EX Hi Cap
Samsung SL-M3320/M3370/M3820/M3870/M4020/M4070	Samsung MLT D203U Ultra Hi Cap
Samsung SL-M3320/M3370/M3820/M3870/M4020/M4070	Samsung MLT D203L Hi Cap
Samsung SL-M3320/M3370/M3820/M3870/M4020/M4070	Samsung MLT D203S Std Cap
Samsung ProXpress M3325/3375/M3825/M3875/M4025/M4075	Samsung MLT D204 INTRO
Samsung ProXpress M3325/3375/M3825/M3875/M4025/M4075	Samsung MLT D204E ex Hi Cap
Samsung ProXpress M3325/3375/M3825/M3875/M4025/M4075	Samsung MLT D204L Hi Cap
Samsung ProXpress M3325/3375/M3825/M3875/M4025/M4075	Samsung MLT D204S Std Cap
Samsung ML-3310ND / ML-3312ND / ML-3712DW / SCX-4833 / SCX-5637FR	Samsung MLT D205 Extra Hi Cap
Samsung ML-3310ND / ML-3312ND / ML-3712DW / SCX-4833 / SCX-5637FR	Samsung MLT D205L High Cap
Samsung ML-3310ND / ML-3312ND / ML-3712DW / SCX-4833 / SCX-5637FR	Samsung MLT D205S Std Cap
Samsung SCX-5635FN / SCX-5835NX	Samsung MLT D2082L Hi Cap
Samsung SCX-5635FN / SCX-5835NX	Samsung MLT D2082S Std Cap
Samsung SCX-4824 / 4825 / 4828 / ML-2855	Samsung MLT D2092L Hi Cap
Samsung SCX-4824 / 4825 / 4828 / ML-2855	Samsung MLT D2092S Std Cap
Samsung MultiXpress M4580FX	Samsung MLT D303E/ELS
Samsung MultiXpress M4580FX	Samsung MLT D303 INTRO
Samsung SL-M4530ND/M4530NX/SL-M4583FX	Samsung MLT D304S Std Cap
Samsung SL-M4530ND/M4530NX/SL-M4583FX	Samsung MLT D304L Hi Cap
Samsung SL-M4530ND/M4530NX/SL-M4583FX	Samsung MLT D304E Ex Hi Cap
Samsung SL-M4530ND/M4530NX/SL-M4583FX	Samsung MLT D304 INTRO
Samsung ML-3750ND	Samsung MLT D305S Std Cap
Samsung ML-3750ND	Samsung MLT D305L Hi Cap
Samsung ML 4510ND / ML 4512ND / ML5012ND	Samsung MLT D307E Ex Hi Cap
Samsung ML 4510ND / ML 4512ND / ML5012ND	Samsung MLT D307S Std Cap
Samsung ML 4510ND / ML 4512ND / ML5012ND	Samsung MLT D307L Hi Cap
Samsung ML 4510ND / ML 4512ND / ML5012ND	Samsung MLT D307U Ultra Ex Hi Cap
Samsung ML-5510ND/5515ND/6510ND/6515ND	Samsung MLT D309E Ex Hi Cap
Samsung ML-5510ND/5515ND/6510ND/6515ND	Samsung MLT D309L Hi Cap
Samsung ML-5510ND/5515ND/6510ND/6515ND	Samsung MLT D309S Std Cap
Samsung SL-K7400GX/LX/K7500GX/K7500LX	Samsung MLT K706S
Samsung SCX-8123NA/8128NA/8128NX	Samsung MLT D709S/ELS
Samsung Xpress M2675 / M2825/ M2875FD	Samsung MLT R116 Drum
Samsung ProXpress M3325/3375/M3825/M3875/M4025/M4075	Samsung MLT R204 Drum
Samsung MLT R304 Drum	Samsung MLT R304 Drum
Samsung ML 4512ND / ML5012ND	Samsung MLT R307 Drum
Samsung ML-5510ND/5515ND/6510ND/6515ND	Samsung MLT R309 Drum
Samsung CLP-360/365/CLX-3300/3305/Xpress SL-C410/430/460/480	Samsung CLT R406 Drum
Samsung CLP-320/320N/325/325W/CLX-3185/3185N/3185FN/3185FW	Samsung CLT R407 Drum
Samsung CLP-310 / 315 / CLX 3170fn / 3176	Samsung CLT R409 Drum
Samsung CLT R504 Drum	Samsung CLT R504 Drum
Samsung CLT R506 Drum	Samsung CLT R506 Drum
Samsung CLT R508 Drum	Samsung CLT R508 Drum
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT R607 Drum Black
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT R607 Drum Cyan
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT R607 Drum Magenta
Samsung CLX 9250 / 9252 / 9350 / 9352	Samsung CLT R607 Drum Yellow
Samsung CLT R609 Drum	Samsung CLT R609 Drum
Samsung SCX-4200 Series	Samsung SCX 4200
Samsung SCX-6320	Samsung SCX 6320
Samsung SCX-6320 / Xerox 113R00671	Samsung SCX 6320 Drum
Samsung SCX-6545N/6545NX/6555N/6555NX	Samsung SCX D6555 Black
Samsung SCX-6545N/6545NX/6555N/6555NX	Samsung SCX R6555A/SEE Drum
Samsung SF-560R	Samsung SF 560R
Remanufactured / Refilled Samsung Laser Printers	Remanufactured / Refilled Samsung Laser Printers
Sharp Laser Printers	Sharp Laser Printers
Sharp DX-C20 Black	Sharp DX-C20 Black
Sharp DX-C20 Cyan	Sharp DX-C20 Cyan
Sharp DX-C20 Magenta	Sharp DX-C20 Magenta
Sharp DX-C20 Yellow	Sharp DX-C20 Yellow
Sharp DX-C20 Black INTRO	Sharp DX-C20 Black INTRO
Sharp DX-C20 Cyan INTRO	Sharp DX-C20 Cyan INTRO
Sharp DX-C20 Magenta INTRO	Sharp DX-C20 Magenta INTRO
Sharp DX-C20 Yellow INTRO	Sharp DX-C20 Yellow INTRO
Sharp MX-60 Black	Sharp MX-60 Black

Sharp MX-60 Cyan Sharp MX-60 Magenta Sharp MX-60 Yellow	Sharp MX-60 Cyan Sharp MX-60 Magenta Sharp MX-60 Yellow
Remanufactured / Refilled Sharp Laser Printers	Remanufactured / Refilled Sharp Laser Printers
Xerox Laser Printers	Xerox Laser Printers
Xerox WorkCentre 7525/7530/7535/7545/7556/7830/7835/7845/7855/7970/	Xerox 006R01513 Black
Xerox WorkCentre 7525/7530/7535/7545/7556/7830/7835/7845/7855/7970/	Xerox 006R01514 Yellow
Xerox WorkCentre 7525/7530/7535/7545/7556/7830/7835/7845/7855/7970/	Xerox 006R01515 Magenta
Xerox WorkCentre 7525/7530/7535/7545/7556/7830/7835/7845/7855/7970/	Xerox 006R01516 Cyan
Xerox Phaser 6100	Xerox 106R00676 Cyan Std Cap
Xerox Phaser 6100	Xerox 106R00677 Magenta Std Cap
Xerox Phaser 6100	Xerox 106R00678 Yellow Std Cap
Xerox Phaser 6100	Xerox 106R00679 Black Std Cap
Xerox Phaser 6100	Xerox 106R00680 Cyan Hi Cap
Xerox Phaser 6100	Xerox 106R00681 Magenta Hi Cap
Xerox Phaser 6100	Xerox 106R00682 Yellow Hi Cap
Xerox Phaser 6100	Xerox 106R00684 Black Hi Cap
Xerox Phaser 7400	Xerox 106R01077 Cyan Hi Cap
Xerox Phaser 7400	Xerox 106R01078 Magenta Hi Cap
Xerox Phaser 7400	Xerox 106R01079 Yellow Hi Cap
Xerox Phaser 7400	Xerox 106R01080 Black Hi Cap
Xerox Phaser 7400	Xerox 106R01150 Cyan Std Cap
Xerox Phaser 7400	Xerox 106R01151 Magenta Std Cap
Xerox Phaser 7400	Xerox 106R01152 Yellow Std Cap
Xerox Phaser 7760	Xerox 106R01164 Cyan
Xerox Phaser 7760	Xerox 106R01165 Magenta
Xerox Phaser 7760	Xerox 106R01166 Yellow
Xerox Phaser 7760	Xerox 106R01167 Black
Xerox Phaser 3100MFP	Xerox 106R01378
Xerox Phaser 3100MFP	Xerox 106R01379 (HC)
Xerox Phaser 6280	Xerox 106R01388 Cyan Std Cap
Xerox Phaser 6280	Xerox 106R01389 Magenta Std Cap
Xerox Phaser 6280	Xerox 106R01390 Yellow Std Cap
Xerox Phaser 6280	Xerox 106R01391 Black Std Cap
Xerox Phaser 6280	Xerox 106R01392 Cyan Hi Cap
Xerox Phaser 6280	Xerox 106R01393 Magenta Hi Cap
Xerox Phaser 6280	Xerox 106R01394 Yellow Hi Cap
Xerox Phaser 6280	Xerox 106R01395 Black Hi Cap
Xerox Phaser 7500	Xerox 106R01433 / 106R01436 Cyan
Xerox Phaser 7500	Xerox 106R01435 / 106R01438 Yellow
Xerox Phaser 7500	Xerox 106R01437 / 106R01434 Magenta
Xerox Phaser 7500	Xerox 106R01439 Black
Xerox Phaser 6121	Xerox 106R01463 Cyan Std Cap
Xerox Phaser 6121	Xerox 106R01464 Magenta Std Cap
Xerox Phaser 6121	Xerox 106R01465 Yellow Std Cap
Xerox Phaser 6121	Xerox 106R01466 Cyan Hi Cap
Xerox Phaser 6121	Xerox 106R01467 Magenta Hi Cap
Xerox Phaser 6121	Xerox 106R01468 Yellow Hi Cap
Xerox Phaser 6121	Xerox 106R01469 Black Hi Cap
Xerox Phaser 6700	Xerox 106R01503 Std Cap Cyan
Xerox Phaser 6700	Xerox 106R01504 Std Cap Magenta
Xerox Phaser 6700	Xerox 106R01505 Std Cap Yellow
Xerox Phaser 6700	Xerox 106R01506 Std Cap Black
Xerox Phaser 6700	Xerox 106R01507 Hi Cap Cyan
Xerox Phaser 6700	Xerox 106R01508 Hi Cap Magenta
Xerox Phaser 6700	Xerox 106R01509 Hi Cap Yellow
Xerox Phaser 6700	Xerox 106R01510 Hi Cap Black
Xerox Phaser 7800	Xerox 106R01563 Cyan
Xerox Phaser 7800	Xerox 106R01564 Magenta
Xerox Phaser 7800	Xerox 106R01565 Yellow
Xerox Phaser 7800	Xerox 106R01566 Cyan
Xerox Phaser 7800	Xerox 106R01567 Magenta
Xerox Phaser 7800	Xerox 106R01568 Yellow
Xerox Phaser 7800	Xerox 106R01569 Black
Xerox Phaser 7100	Xerox 106R02599 Cyan Std Cap
Xerox Phaser 7100	Xerox 106R02600 Magenta Std Cap
Xerox Phaser 7100	Xerox 106R02601 Yellow Std Cap
Xerox Phaser 7100	Xerox 106R02605 Black Hi Cap
Xerox Phaser 3610 / WorkCentre 3615	Xerox 106R02731 Black Ex hi Cap
Xerox Phaser 3610 / WorkCentre 3615	Xerox 106R02722 Black Hi Cap
Xerox Phaser 3610 / WorkCentre 3615	Xerox 106R02720 Black Std Cap
Xerox Phaser 3610 / WorkCentre 3615	Xerox 106R02724 Black

Xerox Phaser 3020 / WorkCentre 3025	Xerox 106R02773 Black
Xerox Phaser 6510 / WorkCentre 6515	Xerox 106R03476 Black Hi Cap
Xerox Phaser 6510 / WorkCentre 6515	Xerox 106R03477 Cyan Hi Cap
Xerox Phaser 6510 / WorkCentre 6515	Xerox 106R03478 Magenta Hi Cap
Xerox Phaser 6510 / WorkCentre 6515	Xerox 106R03479 Yellow Hi Cap
Xerox N24 / N32 / N40	Xerox 113R00184
Xerox Phaser 4500	Xerox 113R00656 Std Cap
Xerox Phaser 4500	Xerox 113R00703 Hi Cap
Xerox WorkCentre M15 / M15i / Pro 312 / 413	Xerox 113R00663 Drum
Xerox Phaser 4510	Xerox 113R00711 Std Cap
Xerox Phaser 4510	Xerox 113R00712 / 715 Hi Cap
Xerox Phaser 6180	Xerox 113R00719 Std Cap Cyan
Xerox Phaser 6180	Xerox 113R00720 Std Cap Magenta
Xerox Phaser 6180	Xerox 113R00721 Std Cap Yellow
Xerox Phaser 6180	Xerox 113R00722 Std Cap Black
Xerox Phaser 6180	Xerox 113R00723 Hi Cap Cyan
Xerox Phaser 6180	Xerox 113R00724 Hi Cap Magenta
Xerox Phaser 6180	Xerox 113R00725 Hi Cap Yellow
Xerox Phaser 6180	Xerox 113R00726 Hi Cap Black
Xerox Phaser 6180 "Metered"	Xerox 113R00731 Cyan
Xerox Phaser 6180 "Metered"	Xerox 113R00732 Magenta
Xerox Phaser 6180 "Metered"	Xerox 113R00733 Yellow
Xerox Phaser 6180 "Metered"	Xerox 113R00734 Black
Remanufactured / Refilled Xerox Laser Printers	Remanufactured / Refilled Xerox Laser Printers
All Fusers	All Fusers
All HP Fusers	All HP Fusers
All Lexmark Fusers	All Lexmark Fusers
All Brother Fusers	All Brother Fusers
All Canon Fusers	All Canon Fusers
All Dell Fusers	All Dell Fusers
All Epson Fusers	All Epson Fusers
All IBM Fusers	All IBM Fusers
Phones for recycling	Phones for recycling
Mobile Phones For Recycling (No Battery)	Mobile Phones For Recycling (No Battery)